



EPROM Programmer
 Designed April 2008
 Stuart Conner

If using with the CF7+ Compact Flash Drive and a Y-cable splitter, you may need to cut the CRUIN line at pin 33 of the CF7+ edge connector and insert a 1K resistor, otherwise the CF7+ keeps this line pulled high when accessing the TMS 9901.