



TEXAS INSTRUMENTS

TM 990

TM 990
EXPERIMENT



MICROPROCESSOR SERIES™

MANUAL HISTORY

This edition contains the following revisions:

<u>Date</u>	<u>Revision Change</u> <u>(From - to)</u>	<u>ECN Number</u>
3/03/83	D to E	461913

IMPORTANT NOTICES

Texas Instruments reserves the right to make changes at any time in order to improve design and to supply the best product possible.

Texas Instruments cannot assume any responsibility for any circuits shown or represent that they are free from patent infringement.

Copyright © 1983

Texas Instruments Incorporated

PREFACE

This document describes two Texas Instruments memory expansion boards: the TM 990/201 EPROM/RAM expansion board and the TM 990/206 RAM-only expansion board. Essentially, the TM 990/206 board is the TM 990/201 board with only the latter board's RAM circuitry and without its EPROM circuitry. The RAM circuitry is the same for both boards. The TM 990/201 is presented in detail in Sections 1 to 4, and the differences between the TM 990/201 and TM 990/206 are described in Section 5.

TMEM 2008 MEMORY EXPANSION MODULE

FEATURES

The TMEM 2008 memory expansion module has the following features:

- operates on the TM 990/103 microcomputer.
- provides an additional 16K of SRAM (through eight 20-pin sockets) to allow Main Memory expansion.
- connects to the host board via two 28-pin sockets and one 14-position header (J1).

SPECIFICATIONS

The TMEM 2008 has a temperature range of 0 to 70° C with forced air cooling of at least 100 linear feet per minute. The module requires a supply voltage of 5.0 Vdc \pm 5%. The TMEM 2008-1 module has a 55 ns RAM access time.

The 20-pin sockets are populated with '4K x 4 high performance static RAMs.

The pinouts of the 14-pin header J1 are:

Pins	Signal	Pins	Signal
1-4	no connection	11	A3
5	CSC (selects U2, U4 data)	12	A4
6	CSD (selects U6, U8 data)	13	WE-
7-10	no connection	14	no connection




FIGURE 1. TMEM 2008 MEMORY EXPANSION MODULE

INSTALLATION PROCEDURE FOR THE TMEM 2008 MODULE

1. Turn off the power supply connected to the TM 990/103 microcomputer.
2. To expand Main Memory, remove the chips installed in sockets U43 and U51 and also remove the PAL in U19 and store them for future use; they will need to be reinserted in the TM 990/103 board if the TMEM 2008 is removed. A separate PAL (labelled U19 2008/2204) which contains the memory map for the TMEM 2008 is provided. Insert the 2008/2004 PAL in U19. Set switch S2 to all ON. RAM memory will be contiguous from A000₁₆ to FFFE₁₆.

TABLE OF CONTENTS

1.	INTRODUCTION	
1.1	General.....	1-4
1.2	Manual Organization.....	1-4
1.3	Specifications.....	1-4
1.4	Applicable Documents.....	1-4
2.	INSTALLATION AND OPERATION	
2.1	General.....	2-1
2.2	Required Equipment.....	2-1
2.3	Unpacking.....	2-1
2.4	Power and Terminal Hookup.....	2-1
2.5	Memory Mapping.....	2-2
2.6	Memory Access Speed.....	2-2
2.7	Board Access Time.....	2-2
2.8	Operation.....	2-2
2.9	Examples.....	2-2
2.9.1	Set-up with TM 990/100MA or TM 990/101MA Microcomputer..	2-2
2.9.1.1	Configure Memory Map.....	2-4
2.9.1.2	Select Wait State.....	2-4
2.9.2	Set-up with TM 990/1481 Microcomputer.....	2-4
2.9.2.1	Configure Memory Map.....	2-5
2.9.2.2	Select Wait State.....	2-5
3.	MEMORY PLACEMENT AND SELECTION	
3.1	General.....	3-1
3.2	Memory Placement.....	3-1
3.2.1	Memory Configuration Switch Array (S1).....	3-1
3.2.2	Memory Placement by Blocks.....	3-7
3.2.2.1	EPROM Examples.....	3-7
3.2.2.2	RAM Example.....	3-8
4.	THEORY OF OPERATION	
4.1	General.....	4-1
4.2	Static RAM Section.....	4-1
4.3	EPROM Section.....	4-2
4.4	Address Map Options.....	4-2
4.5	EPROM Decode Logic.....	4-2
4.6	RAM Decode Logic.....	4-5
4.7	Addressing Summary.....	4-5
4.8	Memory Speed and Timing.....	4-5
4.8.1	Memory Speed.....	4-5
4.8.2	Memory Timing.....	4-7
4.8.3	READY Logic.....	4-9
4.9	RAM Precedence Logic.....	4-9
4.10	Interface Description.....	4-9
5.	TM 990/206 RAM-ONLY MEMORY EXPANSION BOARD	
5.1	General.....	5-1
5.2	Specifications.....	5-1
5.3	Installation and Operation.....	5-3
5.4	Memory Placement and Selection.....	5-3
5.5	Operation.....	5-3
5.6	Example.....	5-4
5.6.1	Configure Memory Map.....	5-4
5.6.2	Select Wait State.....	5-4

APPENDICES

- A. Programming Address Decode PROMs for Alternate Address Maps
- B. TM 990/201 Schematics
- C. PROM Program Sheets
- D. TM 990/422 Demonstration Software
- E. Parts List

LIST OF ILLUSTRATIONS

Figure 1-1	TM 990/201 Memory Expansion Board.....	1-2
Figure 1-2	Board Dimensions.....	1-3
Figure 2-1	TM 990/201 Memory Map Example.....	2-3
Figure 2-2	TM 990/201-44 Memory Map Example.....	2-5
Figure 3-1	Memory Configuration Switch.....	3-2
Figure 3-2	TM 990/201-41, -42, -43 EPROM Memory Configurations.....	3-3
Figure 3-3	TM 990/201-44 EPROM Memory Configurations.....	3-4
Figure 3-4	TM 990/201-41, -42, -43 RAM Memory Configurations.....	3-5
Figure 3-5	TM 990/201-44 RAM Memory Configurations.....	3-6
Figure 3-6	Memory Block Locations.....	3-9
Figure 4-1	TM 990/201 Block Diagram.....	4-1
Figure 4-2	TM 990/201 Address Decode Logic Block Diagram.....	4-3
Figure 4-3	EPROM Decode Logic.....	4-4
Figure 4-4	RAM Decode Logic.....	4-6
Figure 4-5	SLOW/FAST Memory Jumper Placement.....	4-7
Figure 4-6	TM 990/201 Memory Timing.....	4-8
Figure 4-7	TM 990/201 RAM Ready Logic.....	4-10
Figure 4-8	RAM Precedence Logic.....	4-11
Figure 4-9	TM 990/510A OEM Chassis Backplane Schematic.....	4-11
Figure 5-1	TM 990/206 Memory Expansion Board.....	5-2
Figure 5-2	TM 990/206 Memory Map Example.....	5-5
Figure 5-3	RAM (only) Configuration for Model TM 990/206.....	5-6
Figure A-1	Decode PROM Functional Diagrams.....	A-3
Figure A-2	TM 990/201 RAM Decode PROM Program.....	A-4
Figure A-3	TM 990/201 EPROM Decode Program.....	A-5

LIST OF TABLES

Table 1-1	TM 990/201 Product Matrix.....	1-1
Table 1-2	TM 990/201 Power Consumption vs. Sizes.....	1-4
Table 2-1	Memory Access Time and J1/J2 Settings.....	2-2
Table 4-1	FAST/SLOW Jumper (J1/J2) Positions vs Memory Access Time.....	4-7
Table 4-2	Backplane/P1 Pin Assignments used by TM 990/201 Board.....	4-12
Table 5-1	TM 990/206 Product Matrix.....	5-1
Table 5-2	TM 990/206 Power Consumption vs Sizes.....	5-3
Table A-1	RAM PROM Decode Programming Example.....	A-2

SECTION 1

INTRODUCTION

1.1 GENERAL

Sections 1 to 4 present detailed information on the TM 990/201 EPROM/RAM memory expansion board. Section 5 covers the TM 990/206 RAM-only memory expansion board and how it differs from the TM 990/201 board. Information applicable to the RAM configurations in Sections 1 to 4 is applicable to the TM 990/206.

The Texas Instruments TM 990/201 is an expansion memory board (shown in Figure 1-1) for use with the TM 990/100MA or TM 990/101MA microcomputers. The TM 990/201-44 expansion memory board is designed for use with the TM 990/1481 microcomputer. Features for the TM 990/201 boards include:

- Up to 8K words of 2114 static RAM (1024 x 4 bits each)
- Up to 16K words of TMS 2716 EPROM (2048 x 8 bits each)
- TTL compatible interface
- 3 MHz operating capability (5 MHz for TM 990/201-44)

The TM 990/201 is available in four versions as shown in Table 1-1. Access to the board is through the edge connector which mates to the backplane of the TM 990/510A OEM chassis (or the equivalent). The TM 990/201 board is not compatible with the TM 990/180M board which operates with an 8-bit data bus.

On Model TM 990/201-41, sockets are provided for 4K words of static RAM and 8K words of EPROM; however, only 2K words of RAM and 4K words of EPROM are populated. The TM 990/201-42, -43, -44 boards are totally socketed for up to 8K words of RAM and 16K words of EPROM and are populated in accordance with Table 1-1. Information in parentheses in Table 1-1 refers to the name of the memory block populated at the factory. Figure 1-2 shows memory board dimensions (for the TM 990/201 and /206). The TM 990/206 product matrix is shown in section 5.1, Table 5-1.

TABLE 1-1. TM 990/201 PRODUCT MATRIX

Model	Sockets Provided		Sockets Populated		RAM Access Time
	RAM	EPROM	RAM	EPROM	
TM 990/201-41	4K x 16 (RBLK0-RBLK1)	8K x 16 (EBLK4-EBLK7)	2K x 16 (RBLK0)	4K x 16 (EBLK6,EBLK7)	450 ns
TM 990/201-42	8K x 16 (RBLK0-RBLK3)	16K x 16 (EBLK0-EBLK7)	4K x 16 (RBLK0-RBLK1)	8K x 16 (EBLK4-EBLK7)	450 ns
TM 990/201-43	8K x 16 (RBLK0-RBLK3)	16K x 16 (EBLK0-EBLK7)	8K x 16 (RBLK0-RBLK3)	16K x 16 (EBLK0-EBLK7)	450 ns
TM 990/201-44	8K x 16 (RBLK0-RBLK3)	16K x 16 (EBLK0-EBLK7)	8K x 16 (RBLK0-RBLK3)	-0-	200 ns

Note: Block nomenclature explained in Section 3.




FIGURE 1-1. TM 990/201 MEMORY EXPANSION BOARD




FIGURE 1-2. BOARD DIMENSIONS (IN INCHES)

1.2 MANUAL ORGANIZATION

Section 2 of this manual describes the correct procedure for installation, power-up, and operation of the TM 990/201 memory expansion board. Section 3 discusses memory mapping and operation of switch array S1 as well as jumpers J1 and J2. Section 4 discusses the theory of operation, including timing considerations and addressing. Section 5 outlines the differences between the TM 990/206 and the TM 990/201.

1.3 SPECIFICATIONS

Board Dimensions: See Figure 1-2.

Temperature Range: Operating 0°C to 70°C
Storage -40°C to 100°C

Clock rate: The TM 990/201 memory expansion board is compatible with the TM 990/100MA or TM 990/101MA CPU at 3 MHz. The TM 990/201-44 is compatible with the TM 990/1481 CPU at 5 MHz.

Devices Used: 2114 static RAM, 1K x 4
TMS 2716 EPROM, 2K x 8, 450 ns access time

Power: See Table 1-2.

1.4 APPLICABLE DOCUMENTS

- TM 990/100MA Microcomputer User's Guide
- TM 990/101MA Microcomputer User's Guide
- TM 990/1481 High-Performance CPU Module
- TMS 9900 Microprocessor Data Manual
- 74S481 Bit Slice Manual

TABLE 1-2. TM 990/201 POWER CONSUMPTION VS. SIZES

Model	Memory Size	+5V		+12V		-12V	
		Max	Typ	Max	Typ	Max	Typ
TM 990/201-41	2K RAM, 4K EPROM	2.5 A	1.0	.18 A	.16	.5 A	.05
TM 990/201-42	4K RAM, 8K EPROM	3.0 A	1.4	.38 A	.225	.55 A	.125
TM 990/201-43	8K RAM, 16K EPROM	5.5 A	2.15	.75 A	.475	.7 A	.225
TM 990/201-44	8K RAM, 16K EPROM	5.5 A	2.2	.75 A	.475	.7 A	.225

Note: Voltage tolerance $\pm 5\%$ for all supplies.

SECTION 2

INSTALLATION AND OPERATION

2.1 GENERAL

This section explains the procedure for unpacking and setting up the TM 990/201 board for operation with a TM 990/100MA or TM 990/101MA microcomputer. The TM 990/201-44 can also be used with the TM 990/1481 microcomputer (see section 2.9.2 for set-up example).

2.2 REQUIRED EQUIPMENT

- TM 990/510A OEM chassis (or equivalent)
- Power supply that is capable of supplying the power requirements of the memory board (see Table 1-2), CPU, and other installed user equipment.
- Terminal
- TM 990/100MA or TM 990/101MA microcomputer (or TM 990/1481 microcomputer with fan cooled chassis)

2.3 UNPACKING

Take the TM 990/201 board from its carton and remove the protective wrapping. Check the board for any abnormalities that could have occurred in shipping, and report any discrepancies to your supplier.

2.4 POWER AND TERMINAL HOOKUP

This procedure for hooking up a terminal and system power assumes a system of a TM 990/100MA, TM 990/101MA, or TM 990/1481 microcomputer, a TM 990/510A chassis, and a suitable terminal. (See the appropriate CPU User's Guide for description of proper terminals.) The power supply must provide all the necessary power requirements for the CPU board, the memory board, and any other boards the user may be using.

The use of a chassis is recommended because it offers protection from the abuse that a loose board would receive. It also provides termination resistors for the open collector signals used on the bus and allows system flexibility and hookup convenience.

There are two requirements that have to be met for proper operation of the TM 990/201: 1) proper selection of memory map and 2) proper hookup.

If the TM 990/510A chassis is used, the hookup is simple. Place the microcomputer in the first slot(s) of the chassis and place the memory board in the last slot. This positions the memory board between the CPU and the termination resistors on the backplane.

CAUTION

Always remove and insert boards with the power off. Do not insert or remove any board when the power is on as significant damage may result. If power is being supplied from separate power supplies, the system requires that -12 V be turned on first and be turned off last. There is no required sequence in turning on the remaining voltages. This does not apply if the system uses only one power supply.

2.5 MEMORY MAPPING

Care in selection of the memory map is important before powerup. Refer to Section 3 for details in memory placement and selection of address configuration using switch array S1.

2.6 MEMORY ACCESS SPEED

Jumpers J1 and J2 (Figure 1-1) must be set to FAST or SLOW to indicate respectively the access time of the RAM or EPROM memories used. Table 2-1 lists access time and J1/J2 settings. Section 4.8.1 explains these timing constraints in detail.

TABLE 2-1. MEMORY ACCESS TIME AND J1/J2 SETTINGS

Memory Access Time	J1 (RAM) and J2 (EPROM)	
	3 MHz	5 MHz
450 ns	SLOW	SLOW
300 ns	FAST	SLOW
200 ns	FAST	FAST
150 ns	FAST	FAST

2.7 BOARD ACCESS TIME

The maximum board access time for TM 990/201 is 486 ns. The only exception is the RAM access time for the TM 990/201-44 which is 236 ns.

2.8 OPERATION

Essentially the user needs only to choose the correct memory configuration (Section 3), insert the board into the chassis, and apply power to set-up the system for operation.

The operation of the TM 990/201 memory board should be transparent to the user in that no special signals are required other than those supplied through the backplane. If the TM 990/510A chassis (or equivalent) is not used, refer to section 4.10 for interface information.

2.9 EXAMPLES


2.9.1 Set-up with TM 990/100MA or TM 990/101MA Microcomputer

This example assumes the following configurations:


- 1) TM 990/100MA or TM 990/101MA microcomputer
 - 4K x 16 EPROM in memory address (M.A.) 0000_{16} to $1FFF_{16}$
 - 512 x 16 RAM in M.A. $FC00_{16}$ to $FFFF_{16}$
- 2) TM 990/201 expansion board
 - 4K x 16 EPROM
 - 2K x 16 RAM

Figure 2-1 depicts the desired memory map. Note that expansion EPROM resides at address 2000_{16} to $3FFF_{16}$ while expansion RAM on the TM 990/201-41 is to reside in locations $E000_{16}$ to $EFFF_{16}$ of the TM 990/100MA or TM 990/101MA address map.

TM 990/100MA
 TM 990/101MA
 MICROCOMPUTER
 4K X 16 EPROM,
 512 X 16 RAM



TM 990/201-41
 EXPANSION MEMORY
 4K X 16 EPROM,
 2K X 16 RAM



+

=

DESIRED
 SYSTEM MEMORY
 MAP




FIGURE 2-1. TM 990/201 MEMORY MAP EXAMPLE

The user must do four things to the TM 990/201-41 prior to interfacing the unit to the microcomputer:

- 1) Configure the expansion RAM into the TM 990/100MA or TM 990/101MA memory map using switch S1 and memory placement on the board.
- 2) Configure the expansion EPROM into the TM 990/100MA or TM 990/101MA memory map using switch S1 and memory placement on the board.
- 3) Select the wait state for RAM using jumper J1.
- 4) Select the wait state for EPROM using jumper J2.

2.9.1.1 Configure Memory Map

Populate the EPROM and RAM as explained in section 3.2.2 and Figure 3-6.

To map EPROM into the desired address bounds, set the memory configuration switch array (S1) to ON-ON-OFF-OFF as shown in Figure 3-2 (switches 1 to 4).

To map RAM into the desired address bounds, set switch array S1 to OFF-ON-OFF-OFF as shown in Figure 3-4 (switches 5 to 8).

Section 3 explains memory placement, mapping, and selection of S1 switches.

2.9.1.2 Select Wait State

The TM 990/100MA or TM 990/101MA operates at 3 MHz. The TM 990/201-41 is shipped with 2114 RAM's, 450 nsec access time. Thus, place the RAM FAST/SLOW jumper (J1) in the "SLOW" position. The TM 990/201-41 is shipped with TMS 2716 EPROM's which have a 450 nsec access time. Place the EPROM FAST/SLOW jumper (J2) in the "SLOW" position.

The switch array and the FAST/SLOW jumpers are shown in Figure 1-1. Note that each switch of the array is numbered and each switch is designated as either "ON" (a zero) or "OFF" (a one). The FAST/SLOW jumper positions are also marked "FAST" or "SLOW".

2.9.2 Set-up with TM 990/1481 Microcomputer

This example assumes the following configurations:

- 1) TM 990/1481 microcomputer with no on-board memory
- 2) TM 990/201-44 expansion memory board
 - 16K x 16 EPROM
 - 8K x 16 RAM

Figure 2-2 shows a sample memory map achieved with the TM 990/201-44.




FIGURE 2-2. TM 990/201-44 MEMORY MAP EXAMPLE

The user must do four things to the TM 990/201-44 prior to interfacing the unit to the microcomputer.

- Configure the expansion RAM using switch S1
- Configure the expansion EPROM using switch S1
- Select the wait state for RAM using jumper J1
- Select the wait state for EPROM using jumper J2

2.9.2.1 Configure Memory Map

Populate EPROM and RAM as explained in section 3.2.2 and Figure 3-6.

To map EPROM into the desired address bounds as shown in Figure 2-2, set the memory switch array (S1) to ON-ON-ON-ON as shown in Figure 3-3 (switches 1 to 4).


To map RAM into the desired address bounds as shown in Figure 2-2, set the memory switch array (S1) to ON-OFF-OFF-OFF as shown in Figure 3-5 (switches 5 to 8).

Section 3 explains memory placement, mapping, and selection of S1 switches.

2.9.2.2 Select Wait State

TM 990/1481 operates at 5 MHz. The TM 990/201-44 is shipped with 2114 RAM's which have a 200 ns access time. Place the FAST/SLOW jumper (J1) in the "FAST" position. If TMS 2716 EPROMS with 450 ns access time are used, J2 should be in the "SLOW" position.

The switch array and the FAST/SLOW jumpers are shown in Figure 1-1. Note that each switch of the array is numbered and each switch position is designated as either "ON" (a zero) or "OFF" (a one). The FAST/SLOW jumper positions are marked "FAST" or "SLOW".



SECTION 3

MEMORY PLACEMENT AND SELECTION

3.1 GENERAL

This section describes the procedures used to map memory located on the TM 990/201 memory board into the available address space. Switch S1 and address decode PROM's U42 and U44 determine the address space occupied by both EPROM and RAM on the TM 990/201 board. To select a memory address configuration which is compatible with the system memory map, the user must first do the following:

- 1) Determine the quantity of EPROM and RAM to be populated on the board.
- 2) Place the EPROM and RAM devices in their correct physical locations on the board.
- 3) Set the memory configuration switch array (S1) so that the memory on the TM 990/201 board is mapped into an available address space unoccupied on another board in the system. This address space must be large enough to contain the amount of memory on the TM 990/201 board, and it must not conflict with the same addresses populated on another board.

CAUTION

If there are overlaying duplicate addresses on different boards in the configured system, the resulting data bus conflict may cause damage to the data bus drivers on these boards.

3.2 MEMORY PLACEMENT

Settings of memory configuration switch array (S1, center of the board, see Figure 1-1) determine the address configuration that will be decoded by the address decoding circuitry - two SN74S287 PROM's programmed at U42 for decode EPROM and U44 for decode RAM. Switch array S1 selects the memory starting address and the quantity of memory starting at that address.

3.2.1 Memory Configuration Switch Array (S1)

The memory configuration switch array is divided into two parts. The left four slide switches (1 to 4) designate the EPROM configuration. The right four slide switches (5 to 8) designate the RAM configuration. If the switch is set to the ON position, a binary "0" is encoded at the switch. If the switch is set in an OFF position, a binary "1" is encoded. These switch settings designate the four-bit codes that select the EPROM and RAM address configuration. Figure 3-1 shows the memory configuration switch array.

Note that when read right to left (4 to 1 and 8 to 5), the switches form the binary code 0_{16} to F_{16} as used at the top of Figures 3-2 to 3-5 to explain switch settings and memory addresses. Note again that OFF refers to a binary "1" and ON refers to a binary "0". As shown in Figures 3-2 to 3-5, switch array S1 selects the starting address and the quantity of memory decoded. For example, if switches 1 to 4 are set to all ON's, the memory decoder will select all 16 EPROM sockets (16K words) using addresses beginning at 0000_{16} (0000_{16} to $7FFF_{16}$). If switches 1 to 4 are set to OFF-ON-ON-ON respectively,

the memory decoder will decode all EPROM sockets populated using a starting address of 2000_{16} (2000_{16} to $9FFF_{16}$).

Also shown in Figures 3-2 and 3-3 are EPROM memory address configurations for 8K words and 4K words, all switch selectable.


Switch decoding for RAM selection is shown in Figures 3-4 and 3-5. For example, if switches 5 to 8 are set to OFF-OFF-OFF-ON (Figure 3-4), the memory decoder will select 6K of RAM using addresses 0000_{16} to $2FFF_{16}$.

Not all EPROM's or RAM's populated on the board need be selected by switch S1. Memory not selected by the S1 setting will not be enabled although populated on the board. Conversely, if less memory is populated on the board than designated by switch array S1, the decode logic will address memory as if it was populated as shown by S1.

CAUTION

The user must exercise care in configuring the TM 990/201 memory into a system. The memory map of the TM 990/201 must not overlay memory on other boards in the system. The resulting data bus conflict may cause damage to data bus drivers on the TM 990/201 or other boards in the system. Note that Figures 3-2 and 3-4 contain blocks to show the memory configuration on the microcomputer board. Consider this memory when selecting expansion memory configurations.

Figures 3-2 to 3-5 show that setting switches 1 to 4 or 5 to 8 to all OFF (OFF-OFF-OFF-OFF) will disable all EPROM or RAM.



NOTE: SWITCH SETTINGS FURTHER EXPLAINED IN FIGURES 3-2 (EPROM) AND 3-3 (RAM)

FIGURE 3-1. MEMORY CONFIGURATION SWITCH

Note: Switch settings are further explained in Figures 3-2, 3-3 (EPROM) and in Figures 3-4, 3-5 (RAM).



HEX

		SWITCH CODES*													HEX		
		1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP															
		/100MA															
0	0000- 0FFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	
1	1000- 1FFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	
2	2000- 2FFF	ON	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	
3	3000- 3FFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
4	4000- 4FFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
5	5000- 5FFF	16K WORDS (16 2716's)		8K WORDS (8 2716's)		8K WORDS (8 2716's)		8K WORDS (8 2716's)		8K WORDS (8 2716's)		8K WORDS (8 2716's)		8K WORDS (8 2716's)		EPROM DISABLED	
6	6000- 6FFF	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	
7	7000- 7FFF	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	
8	8000- 8FFF	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	
9	9000- 9FFF	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	EBLK7	
A	A000- AFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	
B	B000- BFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	
C	C000- CFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	
D	D000- DFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	
E	E000- EFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	
F	F000- FFFF	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	EBLK0	

*OFF = binary "1"
ON = binary "0"

FIGURE 3-2. TM 990/201-41, -42, -43 EPROM MEMORY CONFIGURATIONS

SWITCH NO.	HEX MEMORY ADDRESS	SWITCH CODES*																HEX
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
1	0000-0FFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	
2	1000-1FFF	ON	ON	OFF	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	
3	2000-2FFF	ON	ON	ON	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	
4	3000-3FFF	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
	4000-4FFF	EBLK7																
	5000-5FFF					8K WORDS (8 2716's)												
	6000-6FFF									EBLK7								
	7000-7FFF													EBLK4				
	8000-8FFF																	
	9000-9FFF													EBLK0				
	A000-AFFF													16K WORDS (16 2716's)				
	B000-BFFF																	
	C000-CFFF																	
	D000-DFFF																	
	E000-EFFF																	
	F000-FFFF																	
														EPROM DISABLED				
														EBLK7				
														EBLK6				
														4K WORDS (4 2716's)				

FIGURE 3-3. TM 990/201-44 EPROM MEMORY CONFIGURATIONS

*OFF = LOGIC "1"
ON = LOGIC "0"

A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP	SWITCH NO.	SWITCH CODES*																HEX			
				0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F				
0	0000- 0FFF	/100MA	5	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1000- 1FFF	EPROM	6	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON
2	2000- 2FFF	EPROM (EXPAN.)	7	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
3	3000- 3FFF		8	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
4	4000- 4FFF																						
5	5000- 5FFF																						
6	6000- 6FFF																						
7	7000- 7FFF																						
8	8000- 8FFF																						
9	9000- 9FFF																						
A	A000- AFFF																						
B	B000- BFFF																						
C	C000- CFFF																						
D	D000- DFFF																						
E	E000- EFFF	MAPPED I/O																					
F	F000- FFFF	RAM																					

*OFF = 1, ON = 0

FIGURE 3-4. TM 990/201-41, -42. -43 RAM MEMORY CONFIGURATIONS

A0-A3 (HEX)	HEX MEMORY ADDRESS	SWITCH NO.	SWITCH CODES*																HEX	
			0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F		
0	0000- 0FFF	5	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	0000- 0FFF	0
1	1000- 1FFF	6	ON	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	1000- 1FFF	1
2	2000- 2FFF	7	ON	ON	ON	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	2000- 2FFF	2
3	3000- 3FFF	8	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	3000- 3FFF	3
4	4000- 4FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	4000- 4FFF	4
5	5000- 5FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	5000- 5FFF	5
6	6000- 6FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	6000- 6FFF	6
7	7000- 7FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	7000- 7FFF	7
8	8000- 8FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	8000- 8FFF	8
9	9000- 9FFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	9000- 9FFF	9
A	A000- AFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	A000- AFFF	A
B	B000- BFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	B000- BFFF	B
C	C000- CFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	C000- CFFF	C
D	D000- DFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	D000- DFFF	D
E	E000- EFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	E000- EFFF	E
F	F000- FFFF		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	F000- FFFF	F

* OFF = LOGIC "1"
ON = LOGIC "0"

FIGURE 3-5. TM 990/201-44 RAM MEMORY CONFIGURATIONS

3.2.2 Memory Placement by Blocks

EPROM is organized into eight 2K-word blocks designated EBLK0 to EBLK7; RAM is organized into four 2K-word blocks designated RBLK0 to RBLK3 as shown in Figure 3-6.

Encoded as the beginning of onboard memory are EPROM block 7 (EBLK7) and RAM block 0 (RBLK0). In other words, memory decode logic will map memory from low to high in the following order of blocks.

<u>EPROM</u>	<u>RAM</u>
EBLK7 (lowest address)	RBLK0 (lowest address)
EBLK6	RBLK1
EBLK5	RBLK2
EBLK4	RBLK3 (highest address)
EBLK3	
EBLK2	
EBLK1	
EBLK0 (highest address)	

As shown in Figure 3-6, each block of RAM consists of two 4-chip rows of 2114's. Each row consists of 1K by 16-bits, with the bottom row at the lower addresses and the upper row at the higher addresses.

3.2.2.1 EPROM Examples

If the memory configuration switch is set to a code of OFF-ON-OFF-ON (Figure 3-2), indicating 8K words of EPROM, the following will be mapped by the memory decode logic:

<u>BLOCK</u>	<u>MEMORY ADDRESS</u>
EBLK7	1000 ₁₆ to 1FFF ₁₆
EBLK6	2000 ₁₆ to 2FFF ₁₆
EBLK5	3000 ₁₆ to 3FFF ₁₆
EBLK4	4000 ₁₆ to 4FFF ₁₆

NOTE

Even though other EPROM blocks may be populated, only those denoted in Figure 3-2 will be selected for a given setting of switch S1.

If the memory configuration switch is set to a code of OFF-ON-OFF-OFF (Figure 3-2), indicating 4K of EPROM, the following will be mapped by the memory decode logic:

<u>BLOCK</u>	<u>MEMORY ADDRESS</u>
EBLK7	8000 ₁₆ to 8FFF ₁₆
EBLK6	9000 ₁₆ to 9FFF ₁₆

3.2.2.2 RAM Example

If the memory configuration switch is set to a code of OFF-OFF-OFF-ON (Figure 3-4), the following will be mapped by the memory decode logic:

<u>BLOCK</u>	<u>MEMORY ADDRESS</u>
RBLK0	0000 ₁₆ to 0FFF ₁₆
RBLK1	1000 ₁₆ to 1FFF ₁₆
RBLK2	2000 ₁₆ to 2FFF ₁₆





FIGURE 3-6. MEMORY BLOCK LOCATIONS



SECTION 4

THEORY OF OPERATION

4.1 GENERAL

This section covers the theory of operation of the TM 990/201. Information in the TMS 9900 Microprocessor Data Manual can supplement the material in this section. Figure 4-1 is a block diagram of the TM 990/201 memory board. Figure 1-1 is a picture of the TM 990/201 detailing the position of its primary components.

4.2 STATIC RAM SECTION

The static RAM section of the TM 990/201 expansion memory board uses 2114, 1K x 4-bit static RAM. Table 1-1 defines the product matrix and the amount of RAM on each board. A fully populated TM 990/201 consists of four 2K x 16 blocks of RAM. These blocks are designated RBLK0, RBLK1, RBLK2, and RBLK3.

For the TM 990/201, RBLK0 always appears first in the RAM address space followed by RBLK1. RBLK3 is always the last 2K word block of RAM decoded. The block numbers are designated in silkscreen on the TM 990/201.




FIGURE 4-1. TM 990/201 BLOCK DIAGRAM

4.3 EPROM SECTION

The EPROM section of the TM 990/201 memory board uses TMS 2716, 2K x 8-bit EPROM. Table 1-1 defines the product matrix and the amount of EPROM on each board. A fully populated TM 990/201 consists of eight 2K x 16 blocks of EPROM. These are designated EBLK0 through EBLK7.

EBLK7 is always decoded first in the EPROM address space followed by EBLK6. EBLK0 always appears as the last 2K word block of memory on the TM 990/201. The block numbers are designated in the board's silkscreen.

4.4 ADDRESS MAP OPTIONS

The TM 990/201 can be configured in a variety of way into the address map of a TM 990/100MA or TM 990/101MA microcomputer system. The switch states of switch array S1, an 8-position DIP switch array, uniquely determine the mapping of the TM 990/201 EPROM and RAM memory arrays. Switches 1 through 4 select the mapping of the EPROM memory array. Switches 5 through 8 select the RAM mapping. Figure 4-2 summarizes in block diagram form the address decode logic. Selection of memory mapping using S1 is explained in Section 3.

The possible maps for the EPROM and RAM arrays are shown in Figures 3-2 to 3-5. As explained in Section 3, each switch code corresponds to a unique location of the EPROM or RAM in the memory address space. The switch code implies the starting address of the entire block of EPROM or RAM on the TM 990/201 and the amount of EPROM or RAM selected on the TM 990/201.

The EPROM decode logic maps the EPROM into a contiguous memory space. EPROM block 7 (designated EBLK7 in silkscreen) is mapped into the first 2K word block of this address space followed by block 6 and so on. Block 0 is the last block mapped. This is true of all EPROM mapping options. For code 5 (in Figure 3-2), EBLK7 is mapped into 1000_{16} to $1FFF_{16}$; EBLK6 into 2000_{16} to $2FFF_{16}$; EBLK5 into 3000_{16} to $3FFF_{16}$; and EBLK4 into 4000_{16} to $4FFF_{16}$. All other EPROM blocks are disabled for code 5 even if they are populated.

The RAM decode logic also maps the RAM array into a contiguous address space. RAM block 0 (RBLK0 designated in silkscreen) is always mapped into the first 2K words of the space. This is always followed by block 1 and so on. Block 3 is mapped into the last 2K word block.

The decode logic permits RAM precedence over EPROM if both RAM and EPROM are configured in the same address space. This feature is very convenient in debugging programs which will be ROM resident. They may be debugged in RAM on the TM 990/201. Once they are "clean," they may be programmed directly into EPROM without relocation and the attendant relinking.

4.5 EPROM DECODE LOGIC

Figure 4-3 depicts the EPROM decode logic. Switch positions 1 through 4 select a 16-"nibble" (4 bits, half a byte) block of memory in the 74S287. Each block corresponds to 1 of 12 possible EPROM address maps. Each nibble in the block determines:

- 1) If a block of EPROM is to be selected during the current memory cycle given the current state of address bits A0 to A3.
- 2) Which block of EPROM (EBLK7 through EBLK0) is selected.

The three least significant data bits from the 74S287 PROM (D01 to D03) select the block of EPROM. A state of 0 corresponds to EPROM block 0 while a state of 7 corresponds to EPROM block 7. The most significant bit (D04) enables the 1-of-8 selector along with the memory enable signal (MEMEN.M) from the micro-computer. The 1-of-8 selector (74LS138) develops the EPROM select signals.




FIGURE 4-2. TM 990/201 ADDRESS DECODE LOGIC BLOCK DIAGRAM




FIGURE 4-3. EPROM DECODE LOGIC

4.6 RAM DECODE LOGIC

Figure 4-4 is the logic diagram of the RAM decode logic. S1 switch positions 5 through 8 select a 16 by 4 block of memory in the 74S287 PROM. Each of the 16 blocks in the PROM corresponds to one of the 16 RAM address maps. Each nibble in the block diagram determines:

- 1) If a block of RAM is to be selected during the current memory cycle given the state of address lines A0 to A3.
- 2) Which block of RAM (RBLK0 to RBLK3) is selected.

The two least significant bits of the nibble (D01 and D02) coupled with address bit 4 (EA4) from the microcomputer drive the 1-of-8 decoder in selecting one of the eight 1K x 16-bit banks of RAM. The most significant data bit of the nibble, D04, enables the decoder along with the memory enable signal (MEMEN.M) from the microcomputer. The outputs of the decoder are the select lines to the RAM banks.

The G2B input to the 74LS138 gates the RAM select lines so that no bus conflicts occur between the EPROM and RAM data buffers on the TM 990/201. This is accomplished with NORing the write strobe (WE.M) and data bus in (DBIN) from the microcomputer (detail is shown in Figure 4-8).

4.7 ADDRESSING SUMMARY

- The user has an option of 16 configurations each for RAM and EPROM, and a code OFF-OFF-OFF-OFF at S1 allows the user to disable the memories. These options are explained in detail in Section 3.
- The user has the option of programming his own decode configuration, placing memory on any 2K-word boundary. See Appendix A for details.
- An overlap of RAM and EPROM on board results in RAM dominance. See caution on page 3-2 for overlap from board to board.

4.8 MEMORY SPEED AND TIMING

This section describes memory speed and outlines timing for the TM 990/201 memory board.

4.8.1 Memory Speed

The TMS 9900 interfaces easily with slow memories. This is accomplished through the use of the "wait state" concept. During each memory cycle, the microprocessor samples the READY signal. When READY is active high, it indicates to the microprocessor that memory will be ready to read or write during the next clock cycle. When not-ready is indicated during a memory operation, the TMS 9900 enters a wait state and suspends internal operation until the memory system indicates it is ready to proceed.

The READY signal is generated on the TM 990/201 expansion memory board separately for RAM and EPROM. The board will be populated with TMS 2716 EPROM's that have an access time of 450 ns and 2114 static RAM's that have an access time in accordance with Table 1-1. At 3 MHz, the EPROM's and RAM's with access times in excess of 300 ns require one wait state. There are jumper provisions on the board to disable READY for RAM, EPROM, or both.




FIGURE 4-4. RAM DECODE LOGIC

Jumper J1 designates the memory speed for RAM used, and jumper J2 designates the EPROM speed. Table 4-1 shows the necessary jumper setting according to clock used and memory access time.

TABLE 4-1. FAST/SLOW JUMPER (J1/J2) POSITIONS VERSUS MEMORY ACCESS TIME

Access Time	CPU Operation	
	3 MHz	5 MHz
450 ns	SLOW	SLOW
300 ns	FAST	SLOW
200 ns	FAST	FAST
150 ns	FAST	FAST

Figures 1-1 and 4-5 show the jumper positions on the board for RAM (J1) and EPROM (J2). The jumpers are in the SLOW position; this is how the board is shipped. The TM 990/201-44 is shipped with J1 in the "FAST" position.

The speed setting for RAM and EPROM are for all RAM or all EPROM; therefore, if the addition or replacement of memories becomes necessary, the user must take into account the speed of the devices used. If the access time of the slowest RAM being added is more than 300 ns, the RAM jumper must be placed in the SLOW position. This assumes 3 MHz operation. Refer to Table 4-1 for the proper settings. If the RAM supplied with the board operates in the "FAST" mode and the jumper in the "SLOW" position, system performance will be less than optimal.

4.8.2 Memory Timing

The memory timing for the TM 990/201 board is shown in Figure 4-6. Memory write timing is shown with one wait state and read cycle timing is shown with none.

Care must be taken when interfacing the 2114 static RAM to the TMS 9900. During a write cycle, the chip select (S-) to the RAM's must be held high (inactive) until after WE- goes low. Otherwise the RAM's enter a read mode and enable their output buffers. The output buffers in the RAM's would fight against the data bus drivers and data would be lost. This condition would persist for approximately 1 clock cycle until WE- is output by the TMS 9900 microprocessor.






FIGURE 4-5. SLOW/FAST MEMORY JUMPER PLACEMENT

Note: Only RAM jumper J1 provided on the TM 990/206 board.



(a) READ CYCLE (NO WAITS)



(b) WRITE CYCLE (ONE WAIT)

FIGURE 4-6. TM 990/201 MEMORY TIMING

The hardware on the TM 990/201 memory board resolves this problem. In essence the S- signal to the RAM's is an "OR"ed function of WE and DBIN. This method is recommended whenever devices with common I/O pins are used.

4.8.3 READY Logic

Figure 4-7 depicts the circuitry for the RAM READY logic. The EPROM READY logic is identical. The READY logic forces one wait state during each memory cycle the RAM is accessed.

If jumper J1 is in the FAST position, READY is never asserted low since the left flip-flop's CLR input is always low. Thus READY is never forced low. If J1 is in the SLOW position, READY is forced low for the first ϕ 1 clock period of every RAM memory cycle. The two flip-flops force READY high for the second and third clock cycles as shown in the timing diagram in Figure 4-6.

4.9 RAM PRECEDENCE LOGIC

Figure 4-8 details the RAM precedence logic. During any memory cycle that both RAM and EPROM are selected on the TM 990/201, the EPROM data buffers are placed in the high impedance state. Thus the RAM data buffers are the only buffers allowed to use the data bus.

4.10 INTERFACE DESCRIPTION

All of the interface functions for the TM 990/201 memory board are through the chassis backplane. A pin assignment chart is shown in Table 4-2. The signals used are shown with their corresponding pin number on the P1 connector tab.

Figure 4-9 shows the TM 990/510A chassis backplane.




FIGURE 4-7. TM 990/201 RAM READY LOGIC




FIGURE 4-8. RAM PRECEDENCE LOGIC




FIGURE 4-9. TM 990/510A OEM CHASSIS BACKPLANE SCHEMATIC

TABLE 4-2. BACKPLANE/P1 PIN ASSIGNMENTS USED BY TM 990/201 BOARD

PIN	SIGNAL	PIN	SIGNAL
1	GND	62	A5.B
2	GND	63	A6.B
3	+5	64	A7.B
4	+5	65	A8.B
21	GND	66	A9.B
22	$\bar{\phi}1.B$	67	A10.B
23	GND	68	A11.B
25	GND	69	A12.B
27	GND	70	A13.B
31	GND	71	A14.B
33	D0.B	73	-12V
34	D1.B	74	-12V
35	D2.B	75	+12V
36	D3.B	76	+12V
37	D4.B	77	GND
38	D5.B	78	$\overline{WE}.B$
39	D6.B	79	GND
40	D7.B	80	$\overline{MEMEN}.B$
41	D8.B	81	GND
42	D9.B	82	DBIN.B
43	D10.B	83	GND
44	D11.B	85	GND
45	D12.B	89	GND
46	D13.B	90	READY.B
47	D14.B	91	GND
48	D15.B	97	+5
57	A0.B	98	+5
58	A1.B	99	GND
59	A2.B	100	GND
60	A3.B		
61	A4.B		

SECTION 5

TM 990/206 RAM-ONLY MEMORY EXPANSION BOARD

5.1 GENERAL

The Texas Instruments TM 990/206 is a RAM-only expansion memory board (shown in Figure 5-1) for use with the TM 990/100MA or TM 990/101MA microcomputers. Its features include:

- Up to 8K words of 2114 static RAM (1024 x 4 bits each)
- TTL compatible interface
- 3 MHz operating capability
- Single power supply (+5V)

The operation of the TM 990/206 is essentially the same as the TM 990/201. The differences between the two include:

- The TM 990/206 has no EPROM memory.
- The memory (RAM) configurations differ (the program in the RAM address decode PROM, U44, is also different for the two boards).
- The power requirements differ.

These differences are explained in more detail in sections 5.2 and 5.3.

Table 5-1 defines the product matrix for the TM 990/206 RAM memory board.

TABLE 5-1. TM 990/206 PRODUCT MATRIX

Model	Sockets Provided	Sockets Populated	RAM Access Time
TM 990/206-41	8K x 16 (RBLK0-RBLK3)	4K x 16 (RBLK0-RBLK1)	450 ns
TM 990/206-42	8K x 16 (RBLK0-RBLK3)	8K x 16 (RBLK0-RBLK3)	450 ns

Note: Block nomenclature is shown in Figure 3-4.

5.2 SPECIFICATIONS

Board Dimensions: See Figure 1-2.

Temperature Range: Operating 0°C to 70°C
Storage -40°C to 100°C

Clock rate: The TM 990/206 memory expansion board is compatible with the TM 990/100MA or TM 990/101MA CPU at 3 MHz.




FIGURE 5-1. TM 990/206 MEMORY EXPANSION BOARD

Devices Used: 2114 static RAM, 1K x 4

Power: See Table 5-2.

TABLE 5-2. TM 990/206 POWER CONSUMPTION VS. SIZES

Model	Memory Size	+5V (+ 5%)	
		Max	Typ
TM 990/206-41	4K x 16 RAM	2.5 A	1.3 A
TM 990/206-42	8K x 16 RAM	5.5 A	2.15 A

5.3 INSTALLATION AND OPERATION

Installation and operation of the TM 990/206 board is the same as explained in Section 2 except for the example in section 2.9. An example using the TM 990/206 memory and memory mapping is provided in section 5.6.

5.4 MEMORY PLACEMENT AND SELECTION

The TM 990/206 RAM memory board is decoded in a similar manner as for the TM 990/201 EPROM/RAM board as explained in Section 3 except that the TM 990/206 does not contain EPROM and its RAM configuration differs.

S1 is essentially the same as described in section 3.2.1 except that only switches 5 to 8 are used since this is a RAM-only board. The TM 990/206 memory map is shown in Figure 5-2. RAM block placement is the same as in section 3.2.2:

RBLK0 (lowest address)
RBLK1
RBLK2
RBLK3 (highest address)

Only jumper J1 to select RAM speed is provided on the TM 990/206 board. J1 operates the same for either board as explained in section 2.6.

5.5 OPERATION

Essentially the user needs only to choose the correct memory configuration (Section 3), insert the board into the chassis, and apply power to set up the system for operation.

The operation of the TM 990/206 memory board should be transparent to the user in that no special signals are required other than those supplied through the backplane. If the TM 990/510A (or equivalent) is not used, refer to section 4.10 for interface information.

5.6 EXAMPLE

This example assumes the following configurations:

- 1) TM 990/100MA or TM 990/101MA microcomputer
 - 4K x 16 EPROM in memory address (M.A.) 0000_{16} to $1FFF_{16}$
 - 512 x 16 RAM in M.A. $FC00_{16}$ to $FFFF_{16}$
- 2) TM 990/206 expansion board
 - 4K x 16 RAM

Figure 5-2 depicts the desired memory map. Note that expansion RAM on the TM 990/206-41 is to reside in locations $D000_{16}$ to $FFFF_{16}$ of the TM 990/100MA or TM 990/101MA address map.

The user *must* do two things to the TM 990/206-41 prior to interfacing the unit to the microcomputer:

- 1) Configure the expansion RAM into the TM 990/100MA or TM 990/101MA memory map.
- 2) Configure the wait state for RAM.

5.6.1 Configure Memory Map

To map RAM into the desired address bounds, set switch array S1 to code ON-OFF-OFF-OFF. This provides memory mapping as shown in Figure 5-3.

Section 3 explains memory placement, mapping, and selection of S1 switches.

5.6.2 Select Wait State

The TM 990/100MA or TM 990/101MA operates at 3 MHz. The TM 990/206-41 is shipped with 2114 RAMs, 450 nsec access time. Thus, place the RAM FAST/SLOW jumper (J1) in the "SLOW" position.




FIGURE 5-2. TM 990/201 MEMORY MAP EXAMPLE

A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP	SWITCH NO.	SWITCH CODES*																HEX							
				0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F								
0	0000-0FFF	EPROM	5	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1000-1FFF	EPROM (EXPAN.)	6	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF	ON	ON	OFF
2	2000-2FFF		7	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
3	3000-3FFF		8	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
4	4000-4FFF			8K WORDS (32 2114's)																							
5	5000-5FFF			4K WORDS (16 2114's)																							
6	6000-6FFF			RBLK0																							
7	7000-7FFF			RBLK1																							
8	8000-8FFF			RBLK2																							
9	9000-9FFF			RBLK3																							
A	A000-AFFF			RBLK4																							
B	B000-BFFF																										
C	C000-CFFF																										
D	D000-DFFF																										
E	E000-EFFF	MAPPED I/O																									
F	F000-FFFF	RAM																									

*OFF = 1, ON = 0

FIGURE 5-3. RAM (ONLY) CONFIGURATION FOR MODLE TM 990/206

APPENDIX A

PROGRAMMING ADDRESS DECODE PROMs FOR ALTERNATE ADDRESS MAPS

Figures 3-2 to 3-5 illustrate the mapping options available with the TM 990/201 memory. The purpose of this section is to detail how a user might program the two 74S287 PROMs (256 x 4) to obtain an alternate memory map. Refer to Section 3 and sections 4.4, 4.5, 4.6 for a description of the address decode logic.

Figure A-1 (a) is a simplified illustration of the PROM decode logic for the RAM. The EPROM logic in Figure A-1 (b) is similar except that three data bits (D03, D02, D01) instead of two, are used to select the block number. DIP switch S1 inputs to the PROM select one of sixteen possible memory maps.

The A0-A3 inputs select one of the sixteen 4-bit nibbles (half byte) from the block.

The most significant data bit (D04 from the 74S287) is the memory select or enable bit. If this is a one, the RAM (or EPROM) on the TM 990/201 is being addressed. If a zero, no TM 990/201 memory is addressed during the memory cycle. The two least significant bits (D02 and D01) identify which of the blocks of RAM is addressed. For the EPROM decode PROM, the three least significant bits (D03-D01) identify which of the eight blocks of EPROM is addressed.

For a particular nibble in the PROM, it is a straightforward matter to identify how the bits are programmed. If memory is accessed, the most significant bit is a one. The least significant three bits identify the block number of the memory which is to be accessed.

It is necessary to understand the structure of data in the PROM. The PROM is assumed to consist of a 16 by 16 array of 4-bit nibbles of data for a total of 256 nibbles. For any particular switch setting and state of the address bits A0-A3, the nibble is located by the formula:

$$\text{PROM Address} = 10_{16} \times (\text{A0-A3})_{16} + (\text{Switch Setting})_{16}$$

As an example, assume that for switch setting 2 (switches 5 to 8 = ON-OFF-ON-ON or 0-1-0-0 as shown in Figure 5-3) in the RAM switch, the 8K x 16 RAM is to be located from 0 to 3FFE₁₆ instead of 7000₁₆ to AFFF₁₆, as shown in Figure 3-3. RBLK0 is addressed from 0-OFFE₁₆, RBLK1 from 1000₁₆-1FFE₁₆, RBLK2 from 2000₁₆-2FFE₁₆, and RBLK3 from 3000₁₆ to 3FFE₁₆. RAM is not accessed from 4000₁₆ to FFFE₁₆. Table A-1 details the binary state of each bit in the 16 "nibbles" defined by switch setting 2.

Using the PROM address formula, the PROM address of the first pattern in Table A-1 is

$$\text{PROM Address} = 10_{16} \times (0) + 2_{16} = 2_{16}$$

The PROM address of the tenth pattern is

$$\text{PROM Address} = 10_{16} \times (9)_{16} + 2 = 92_{16}$$

Further study of the above procedure in conjunction with Figures 3-2 to 3-5 leads to a very simple procedure for programming the PROM. Figures 3-2 to 3-5 can be thought of as 16 x 16 matrices. The first row represents the first 16 consecutive nibbles of the PROM, the second row the second 16 nibbles, etc. Thus, filling out such a chart and including the data to be programmed in each nibble in each block of the chart provides a very simple means of documenting the PROM program. Data can easily be entered into a PROM programmer directly from the chart.

TABLE A-1. RAM PROM DECODE PROGRAMMING EXAMPLE


ADDRESS STATE (A0-A3) ₁₆	SWITCH SETTING IN EXAMPLE	DATA PATTERN IN NIBBLE				HEX ADDRESS OF NIBBLE IN PROM	FUNCTION DESCRIPTION
		DO4	DO3	DO2	DO1		
0	2	1	0	0	0	2	Select RBLK0
1	2	1	0	0	1	12	Select RBLK1
2	2	1	0	1	0	22	Select RBLK2
3	2	1	0	1	1	32	Select RBLK3
4	2	0	0	0	0	42	} No RAM Selected
5	2	0	0	0	0	52	
6	2	0	0	0	0	62	
7	2	0	0	0	0	72	
8	2	0	0	0	0	82	
9	2	0	0	0	0	92	
A	2	0	0	0	0	A2	
B	2	0	0	0	0	B2	
C	2	0	0	0	0	C2	
D	2	0	0	0	0	D2	
E	2	0	0	0	0	E2	
F	2	0	0	0	0	F2	

Figure A-2 is a chart filled out for the PROM in the RAM decode logic for the TM 990/201. Figure A-3 is the program for the EPROM decode PROM for the TM 990/201. All blocks in the matrix not filled in have 0's in them.


NOTE

For both EPROM and RAM on the TM 990/201, the memory block numbers are designated in silkscreen. EPROM block 2 is designated EBLK2. RAM block 3 is designated RBLK3.

Appendix C contains four spare PROM program sheets which may be removed and used for detailing alternate memory maps.



(a) RAM DECODE PROM AT U44



(b) EPROM DECODE PROM AT U42

FIGURE A-1. DECODE PROM FUNCTIONAL DIAGRAMS

AD-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP		SWITCH CODES*																HEX					
		/100MA	/101MA	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F						
0	0000-0FFF	EPROM	EPROM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1000-1FFF	EPROM (EXPAN.)	EPROM (EXPAN.)	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2	2000-2FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
3	3000-3FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
4	4000-4FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
5	5000-5FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
6	6000-6FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
7	7000-7FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
8	8000-8FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
9	9000-9FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
A	A000-AFFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
B	B000-BFFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
C	C000-CFFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
D	D000-DFFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
E	E000-EFFF	MAPPED I/O	MAPPED I/O	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
F	F000-FFFF	RAM	RAM	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON


*OFF = 1, ON = 0

FIGURE A-2. TM 990/201 RAM DECODE PROM PROGRAM

A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP		SWITCH CODES*																HEX							
		/100MA	/101MA	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F								
0	0000-0FFF	EPROM	EPROM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1000-1FFF	EPROM (EXPAN.)	EPROM (EXPAN.)	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2	2000-2FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
3	3000-3FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
4	4000-4FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
5	5000-5FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
6	6000-6FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
7	7000-7FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
8	8000-8FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
9	9000-9FFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
A	A000-AFFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
B	B000-BFFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
C	C000-CFFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
D	D000-DFFF			ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
E	E000-EFFF	MAPPED I/O	MAPPED I/O	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
F	F000-FFFF	RAM	RAM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF


FIGURE A-3. TM 990/201 EPROM DECODE FROM PROGRAM


*OFF = 1, ON = 0




APPENDIX B


TM 990/201 & TM 990/206 SCHEMATICS










B-5







B-8



APPENDIX C
PROM PROGRAM SHEETS

SWITCH NO.		SWITCH CODES*																HEX
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	
A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP																
0	0000-00FE	EPROM																
1	1000-10FF	EPROM (EXPAN.)																
2	2000-20FF																	
3	3000-30FF																	
4	4000-40FF																	
5	5000-50FF																	
6	6000-60FF																	
7	7000-70FF																	
8	8000-80FF																	
9	9000-90FF																	
A	A000-A0FF																	
B	B000-B0FF																	
C	C000-C0FF																	
D	D000-D0FF																	
E	E000-E0FF	MAPPED I/O																
F	F000-F0FF	RAM																

*OFF = LOGIC "1"
ON = LOGIC "0"

A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP		SWITCH CODES*																HEX											
		/100MA		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F												
0	0000- 0FFF		EPROM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF		
1	1000- 1FFF		EPROM (EXPAN.)	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF
2	2000- 2FFF			ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
3	3000- 3FFF																														
4	4000- 4FFF																														
5	5000- 5FFF																														
6	6000- 6FFF																														
7	7000- 7FFF																														
8	8000- 8FFF																														
9	9000- 9FFF																														
A	A000- AFFF																														
B	B000- BFFF																														
C	C000- CFFF																														
D	D000- DFFF																														
E	E000- EFFF		MAPPED I/O																												
F	F000- FFFF		RAM																												

*OFF = LOGIC "1"
ON = LOGIC "0"

SWITCH NO. SWITCH CODES* HEX

A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0000-0FFF	/100MA EPROM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1000-1FFF	EPROM (EXPAN.)	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2	2000-2FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
3	3000-3FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
4	4000-4FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
5	5000-5FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
6	6000-6FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
7	7000-7FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
8	8000-8FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
9	9000-9FFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
A	A000-AFFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
B	B000-BFFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
C	C000-CFFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
D	D000-DFFF		ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
E	E000-EFFF	MAPPED I/O	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
F	F000-FFFF	RAM	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF

* OFF = LOGIC "1"
ON = LOGIC "0"

HEX

SWITCH NO.		SWITCH CODES*															
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
A0-A3 (HEX)	HEX MEMORY ADDRESS	MICROCOMPUTER MEMORY MAP															
		/100 MA															
0	0000-0FFE	EPROM															
1	1000-1FFF	EPROM (EXPAN.)															
2	2000-2FFF																
3	3000-3FFF																
4	4000-4FFF																
5	5000-5FFF																
6	6000-6FFE																
7	7000-7FFF																
8	8000-8FFF																
9	9000-9FFF																
A	A000-AFFF																
B	B000-BFFF																
C	C000-CFFF																
D	D000-DFFF																
E	E000-EFFF	MAPPED I/O															
F	F000-FFFF	RAM															

*OFF = LOGIC "1"
ON = LOGIC "0"

APPENDIX D

TM 990/422 DEMONSTRATION SOFTWARE

D.1 GENERAL

Optional TM 990/422 demonstration software is available for verifying RAM memory on the TM 990/201 and TM 990/206 memory boards. The software is provided on two TMS 2716 EPROM chips which can be plugged into the EPROM memory areas on the TM 990/100MA or TM 990/101MA microcomputer board or the TM 990/201 memory board. When plugged into the TM 990/201 memory board, it can verify operation of the EPROM array on that board. This software is executed under the TIBUG monitor and uses the utilities provided by the monitor. A source listing of this software is provided as part of this appendix.

The software is completely relocatable in that it can be plugged into any location on the address map (except those locations which are reserved such as TIBUG workspace, interrupt vectors, or load vectors). The entry point is the first address occupied by the EPROM module.

NOTE

During testing, locations $FF90_{16}$ to $FFFF_{16}$ will be protected from data written to these addresses. This is to ensure protection of the monitor and demonstration software workspaces.

D.2 INSTALLATION

The EPROMs can be installed on either the TM 990/100MA or TM 990/101MA microcomputer board or on the TM 990/201 memory board.

D.2.1 Installation on Microcomputer Board

- a. Turn off power to the system. Remove the microcomputer board.
- b. Remove any EPROMs installed in sockets U43 or U45. Leave the TIBUG EPROMs installed in sockets U42 and U44.
- c. Set jumper J2 to 2716. Set jumper J4 to 16 (indicating 2716). Jumper J3 should remain set at 08 (setting for TIBUG EPROMs).
- d. Install the EPROM marked U43 in socket U43. Install the EPROM marked U45 in socket U45.
- e. Install the board into the system. Reapply power.
- f. Call up the TIBUG monitor (toggle the microcomputer board RESET switch, press the character A on the keyboard).
- g. Using the R command, set the Program Counter (P=) to 1000_{16} .
- h. Using the E command, execute the software demonstration program:

```
?R
W=FFC6
P=2000 1000
?E
```

D.2.2 Installation on TM 990/201 Memory Board

- a. Turn off power to the system. Remove the memory board.
- b. On the memory board, place the two TMS 2716 demonstration software chips on adjacent horizontal EPROM sockets (e.g., U56 and U64) with the lowest numbered chip going to the lowest numbered socket (e.g., the U43-marked chip in U56 and the U45-marked chip in U64).
- c. Install jumper J2 on the memory board to the SLOW position.
- d. Set switches 1 to 4 at S1 to a configuration corresponding to placement of the chips in the memory map. For example, if sockets U56 and U64 are used (this is EBLK7), then any one of the settings can be used as shown in Figure 3-2 or 3-3 of the memory board user's guide. As shown in the figure, EBLK7 is mapped into every memory map configuration selected by switches 1 to 4. The only difference is the beginning address. For example, with switches 1 to 4 set to OFF-ON-ON-ON, EBLK7 starts at address 2000₁₆. This being the case, the demonstration software can be executed with the following interaction with TIBUG:

```
?R
W=FFC6
P=01A4 2000
?E
```

D.3 DEMONSTRATION SOFTWARE COMMANDS

When the demonstration software is executed, it outputs an opening message that asks for which addresses to check. After these initial inputs, a double question mark prompt (??) is output asking for one of the six commands explained in the following paragraphs.

The opening message is shown below:

```
?E
TM990/201-/206 DEMO SOFTWARE REV.A 8/02/78

INPUT HEX START ADDRESS, DEFAULT = 2000=>
```

The input hex start address is the starting memory location at which the demonstration software will begin checking. Enter the desired start address (in hexadecimal); if the default address of 2000₁₆ is desired, enter only a carriage return. Next a prompt will ask for the address at which demonstration software will end its check routine:

```
INPUT HEX END ADDRESS, DEFAULT = F000=>
```

Enter the desired end address; if the default address of F000₁₆ is desired, enter only a carriage return. These start and end address prompts are the same as if the I command was issued (section D.3.2).

If the start address is greater than the end address, the following message is output:

```
***ERROR**
```

To correct, re-enter the values in the proper order. After these interactive messages, a double question mark (??) prompt asks for one of the six commands explained below.

NOTE

Address inputs to the demonstration software prompts should be even hexadecimal values. If an odd value is input, the resulting address will be the odd value minus one (e.g., FE01₁₆ will be interpreted as FE00₁₆).

D.3.1 HELP Command (H)

To obtain a list of the six one-character commands observed by the demonstration software, enter the H command. The following list will be output:

?? H

COMMANDS:

H - HELP, PRINTS THIS HELP LIST

Q - QUIT, BACK TO TIBUG

S - SEARCH FOR RAM BOUNDS

SEARCHES FOR THE FIRST CONTIGUOUS BLOCK OF RAM

I - INITIALIZE MEMORY BOUNDS

P - PATTERN MEMORY

WRITE PATTERN TO ALL LOCATIONS UNDER TEST

V - VERIFY RAM OPERATION

ADDRESSING AND DATA TEST; THE DATA TEST CHECKS EVERY BIT.

THE ADDRESS TEST CHECKS TO SEE THAT ALL THE ADDRESSES ARE UNIQUE.

D.3.2 Initialize Memory Bounds Command (I)

This command sets the memory address bounds. The demonstration software will check memory as defined by the start and end memory address bounds. These addresses are first defined in the opening message (paragraph D.3); the I command provides the same function so that these bounds can be modified as desired. Two interactive messages ask for the starting and end address with default values noted. The start address must be less than the end address; if not, the error message ****ERROR**** will be output as described in paragraph D.3. To accept the default value (2000₁₆ start address and F000₁₆ end address), enter a carriage return. To change the address, enter the new address followed by a carriage return.

The following example changes the start and end addresses to B800₁₆ and C000₁₆ respectively.

?? I

INPUT HEX START ADDRESS, DEFAULT = 2000=> B800

INPUT HEX END ADDRESS, DEFAULT = F000=> C000

D.3.3 Search for RAM Bounds Command (S)

The software checks memory for a contiguous block of RAM. When the block is found, the beginning and ending addresses of the block are printed out. The data in the RAM area is not disturbed. The area of memory searched will be the bounds set at program initialization or by the I command. Even though several different RAM blocks may be present in the search area, only the first

block (lowest address) will be located by this command. After one RAM block is found and a message output, control reverts back to the demonstration software command scanner and the double question mark is printed. If a RAM area is not found, the message:

```
NO MEMORY FOUND
```

will be printed out. If the RAM area exceeds the bounds of the memory to be searched, the search will stop at the search-end location and a message will write out the beginning RAM address and the end address of the search as well as a ******TEST COMPLETE****** message. In the following example, a RAM block was found from addresses B800₁₆ to C000₁₆.

```
?? S
MEMORY UNDER TEST =>B800 TO C000
****TEST COMPLETE****
```

Note that the search routine is also part of the verify command (section D.3.5).

D.3.4 Write/Read Hexadecimal Pattern to RAM Command (P)

The command writes and reads a hexadecimal value (pattern) to and from each location found during the opening message or I command (sections D.3 and D.3.2) or RAM address area found during the search routine (sections D.3.3 and D.3.5). The data read from the memory address is compared to the data pattern sent to verify RAM operation. The data in the memory locations will remain changed to the pattern written.

Following an opening message, the user can choose to use the default pattern value of 0000₁₆ by entering a carriage return or can designate a four-digit hexadecimal pattern to be used followed by a carriage return. A nonhexadecimal input will result in issuing the message ****ERROR**** and the beginning pattern prompt reissued. If the pattern read from a memory location is different than the pattern written, an error message is output showing the location in error, this pattern subroutine is terminated, and program control is returned to the demonstration program command scanner. Error message is as follows:

```
**ERROR**LOCATION 2000
```

The following example sends a pattern of AAAA₁₆ to RAM without an error occurring. Then the user checked three memory addresses, using TIBUG, showing that AAAA₁₆ was written to each.

```
?? P
INPUT HEX PATTERN, DEFAULT = 0000=> AAAA
****TEST COMPLETE****
```

```
?? Q
?M B800
B800=AAAA
B802=AAAA
B804=AAAA
B806=AAAA
?
```

D.3.5 Verify Memory Command (V)

There are three parts to the verify subroutine:

- a. Search routine. This is the same as the search command explained in section D.3.3.
- b. A data check. This is a bit-by-bit check of each RAM memory address. Both a zero and also a one are written to each bit, then read back and checked. If the check showed an error, a message is output. The following example is a message indicating that 02E0₁₆ was read back from location 2000₁₆ when the value read was expected to be 7FFF₁₆.

```
DATA BUS IN ERROR, 7FFF WAS WRITTEN, BUT 02E0 WAS READ BACK
LOCATION 2000
```

- c. A memory address check. The address value of each memory address location is written to each corresponding memory address. The value is read back and compared with the actual address. When the comparison shows an error (not equal), a message is written. The following example is a message indicating that the value 2008₁₆ was readback from memory location 2000₁₆ (2000₁₆ should have been read).

```
ADDRESS PROBLEM FOUND. LOCATION 2000 WAS IN ERROR WITH ADDRESS 2008
```

The verify command will conduct its initial RAM block search within the bounds set by the I command or by initial demonstration software bounds prompts. The following example shows that a RAM block was found from A000₁₆ to C000₁₆, the entire memory under the bounds in the I command. A second block was found at FC00₁₆ to FF00₁₆ after the bounds were reset to conduct a search from D000₁₆ to FF00₁₆. Both test were completed without finding errors.

```
?? I
INPUT HEX START ADDRESS, DEFAULT = A000=> 8000
INPUT HEX END ADDRESS, DEFAULT = C000=> C000
```

```
?? V
MEMORY UNDER TEST =>A000 TO C000
ONE MOMENT PLEASE
****TEST COMPLETE****
```

```
?? I
INPUT HEX START ADDRESS, DEFAULT = A000=> D000
INPUT HEX END ADDRESS, DEFAULT = C000=> FF00
```

```
?? V
MEMORY UNDER TEST =>FC00 TO FF00
ONE MOMENT PLEASE
****TEST COMPLETE****
```

```
??
```

D.3.6 Quit, Return to Monitor Command (Q)

To return to the monitor, enter the character Q. The monitor will respond with its single question mark prompt.

D.4 DEMONSTRATION SOFTWARE LISTING

A listing of the demonstration follows.

```

0002          IDT 'DEMO'
0003          *-----*
0004          *
0005          *      TITLE:      TM990/201-/206 DEMO TEST SOFTWARE
0006          *
0007          *      DATE:      11/16/77
0008          *
0009          *      FUNCTION:   TO DEMONSTRATE/TEST RAM MEMORY ON THE
0010          *                  TM990/201 AND TM990/206 EXPANSION
0011          *                  MEMORY BOARDS
0012          *
0013          *      DESCRIPTION: THIS PROGRAM PROMPTS THE USER FOR RAM
0014          *                  BOUNDS. THESE BOUNDS SET THE ADDRESS
0015          *                  LIMITS FOR TESTING.
0016          *
0017          *      *****THIS PROGRAM IS RELOCATABLE*****
0018          *
0019          *      THE WORKSPACE FOR THIS MODULE STARTS AT >FF90
0020          *
0021          *-----*
0022          *-----REGISTER EQUATES-----*
0023          0000 R0      EQU 0
0024          0001 R1      EQU 1
0025          0002 R2      EQU 2
0026          0003 R3      EQU 3
0027          0004 R4      EQU 4
0028          0005 R5      EQU 5
0029          0006 R6      EQU 6
0030          0007 R7      EQU 7
0031          0008 R8      EQU 8
0032          0009 R9      EQU 9
0033          000A R10     EQU 10
0034          000B R11     EQU 11
0035          000C R12     EQU 12
0036          000D R13     EQU 13
0037          000E R14     EQU 14
0038          000F R15     EQU 15
0039          *****
0040          DXOP HEXI,9
0041          DXOP HEXD,10
0042          DXOP READ,11
0043          DXOP PRNT,14
0044          *****
0045          *XXXX THIS SECTION ALLOWS RELOCATION XXXX
0046          START
0047          0000 02E0          LWPI >FF90          LOAD W.P.
0048          0002 FF90
0048          0004 0201          LI R1,>045B          R1 = RT INSTRUCTION
0049          0006 045B
0049          0008 0681          BL R1          LOAD R11 WITH ADD. OF NEXT INS
0050          000A 022B          AI R11,-10          ADJUST TO START ADD.
0051          000C FFF6
0051          000E C28B          MOV R11,R10          R10 = BASE ADDRESS
0052          *XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
    
```

```

0053 0010 0208      LI   R8,>2000      LOAD DEFAULT START ADD.
      0012 2000
0054 0014 0209      LI   R9,>F000      LOAD DEFAULT END ADD.
      0016 F000
0055 0018 0207      LI   R7,>0000      LOAD DEFAULT PATTERN
      001A 0000
0056 001C 2FAA      PRNT @CRLF(10)
      001E 01F8'
0057 0020 2FAA      PRNT @BANNER(10)      OUTPUT BANNER/DATE
      0022 02A4'
0058 *****
0059 INIT
0060 0024 06AA      BL   @BOUNDS(10)      SET MEMORY BOUNDS
      0026 0497'
0061 *****
0062 INSTR
0063 0028 2FAA      PRNT @PROMPT(10)      OUTPUT PROMPT
      002A 02D9'
0064 002C 2EC5      READ R5
0065 002E 0285      CI   R5,>5600      READ THE COMMAND CHARACTER
      0030 5600      IF IT IS A 'V'=>VERIFY
0066 0032 1317      JEQ  VERIFY
0067 0034 0285      CI   R5,>4900      IF IT IS A 'I'=>INITIALIZE
      0036 4900
0068 0038 13F5      JEQ  INIT
0069 003A 0285      CI   R5,>5100      IF IT IS A 'Q'=>QUIT
      003C 5100
0070 003E 130F      JEQ  QUIT
0071 0040 0285      CI   R5,>4800      IF IT IS A 'H'=>HELP
      0042 4800
0072 0044 1309      JEQ  HELP
0073 0046 0285      CI   R5,>5000      IF IT IS A 'P'=>PATTERN
      0048 5000
0074 004A 131B      JEQ  PAT
0075 004C 0285      CI   R5,>5300      IF IT IS A 'S'=>SEARCH
      004E 5300
0076 0050 1311      JEQ  SEARCH
0077 0052 2FAA      PRNT @INVCMD(10)      OTHERWISE PRINT ERROR
      0054 0563'
0078 0056 10E8      JMP  INSTR          GET NEW COMMAND
0079 *****
0080 HELP
0081 0058 2FAA      PRNT @HLIST(10)      OUTPUT HELP LIST
      005A 02FE'
0082 005C 10E5      JMP  INSTR          GET NEW COMMAND
0083 *****
0084 QUIT
0085 005E 0460      B    @>0080          EXIT, TO TIBUG !
      0060 0080
0086 *****
0087 VERIFY
0088 0062 2FAA      PRNT @CRLF(10)
      0064 01F8'
0089 0066 06AA      BL   @SCAN(10)      FIND THE RAM
  
```



```

0068 018C'
0090 006A 06AA          BL   @TEST(10)          RUN FUNCTIONAL TEST
006C 00F0'
0091 006E 2FAA          PRNT @MSG5(10)         PRINT TEST COMPLETE
0070 01FB'
0092 0072 10DA          JMP  INSTR              GET NEXT INSTRUCTION
0093 *****
0094 SEARCH
0095 0074 2FAA          PRNT @CRLF(10)
0076 01F8'
0096 0078 06AA          BL   @SCAN(10)         ENTER SEARCH
007A 018C'
0097 007C 2FAA          PRNT @MSG5(10)         PRINT TEST COMPLETE
007E 01FB'
0098 0080 10D3          JMP  INSTR              GET NEXT INSTRUCTION
0099 *****
0100 PAT
0101 0082 2FAA          PRNT @CRLF(10)
0084 01F8'
0102 0086 06AA          BL   @PATERN(10)       WRITE PATTERN TO MEMOY
0088 0090'
0103 008A 2FAA          PRNT @MSG5(10)         PRINT TEST COMPLETE
008C 01FB'
0104 008E 10CC          JMP  INSTR              GET NEXT INSTRUCTION
0105 *****
0106 PATERN
0107 0090 0200          LI   R0,>0460           R0 = BRANCH
0092 0460
0108 0094 C080          MOV  R0,R2             R2 = BRANCH
0109 0096 0201          LI   R1,ZIP            <CR><SPACE>OR<-> GO TO ZIP
0098 00B4'
0110 009A A04A          A    R10,R1           ADD BASE ADDRESS
0111 009C 0203          LI   R3,ERROR2        IF ERR BRANCH TO ERROR2
009E 00D8'
0112 00A0 A0CA          A    R10,R3           ADD BASE ADDRESS
0113 OK
0114 00A2 2FAA          PRNT @PROMT(10)       ASK FOR PATTERN
00A4 02E0'
0115 00A6 2E87          HEXO R7               OUTPUT DEFAULT
0116 00A8 2FAA          PRNT @TIC(10)
00AA 0504'
0117 00AC 2E44          HEXI R4               PICK UP PATTERN
0118 00AE FF90          DATA >FF90          POINTS TO R0
0119 00B0 FF94          DATA >FF94          NON-NUMERIC OR INVALID CHAR
0120 00B2 C1C4          MOV  R4,R7            R7 = PATTERN
0121 ZIP
0122 00B4 2FAA          PRNT @CRLF(10)
00B6 01F8'
0123 00B8 C088          MOV  R8,R2            R2 = START ADDRESS
0124 PAT2
0125 00BA CC87          MOV  R7,*R2+         MOV PATTERN TO LOCATION
0126 00BC C112          MOV  *R2,R4          SAVE NEXT LOCATION
0127 00BE 0547          INV  R7              INVERT DATA
0128 00C0 C487          MOV  R7,*R2         DISTURB DATA LINES

```

```

0129 00C2 0642      DECT R2          POINT TO PREV. LOCATION
0130 00C4 C172      MOV *R2+,R5     SAVE DATA
0131 00C6 C484      MOV R4,*R2      RESTORE LOCATION
0132 00C8 0547      INV R7          RESTORE PATTERN
0133 00CA 0642      DECT R2          RESTORE POINTER
0134 00CC 81C5      C R5,R7         COMPARE DATA
0135 00CE 1607      JNE ERR         IF NOT INDICATE
0136 00D0 05C2      INCT R2         INCREMENT ADDRESS
0137 00D2 8242      C R2,R9         DONE?--R9 = END ADDR.
0138 00D4 1AF2      JL PAT2         IF NOT CONTINUE
0139 00D6 100A      JMP RET         OTHERWISE GET NEXT INSTR.
0140
0141 00D8 2FAA      ERROR2 PRNT @ERRMSG(10) PRINT ERROR MSG.
      00DA 0555
0142 00DC 045B      RT
0143
0144 00DE 2FAA      ERR PRNT @ERRMSG(10) PRINT ERROR
      00E0 0555
0145 00E2 2FAA      PRNT @LOC(10) *
      00E4 0574
0146 00E6 2E82      HEX0 R2        PRINT ADDRESS
0147 00E8 2FAA      PRNT @CRLF(10) CLEAR LINE
      00EA 01F8
0148
0149 00EC 045B      RET RT
0150 00EE 1000      NOP
0151
0152 *=====
0153 *
0154 * CHECKS DATA BIT FAILURES
0155 *
0156 * THIS TEST WRITES TO EVERY INDIVIDUAL BIT IN THE
0157 * MEMORY UNDER TEST TWICE, TO VERIFY THAT THE DATA
0158 * BUS IS FUNCTIONAL.
0159 *=====
TEST
0160 00F0 2FAA      PRNT @WAIT(10) OUTPUT WAIT MESSAGE
      00F2 014E
0161 00F4 04C6      CLR R6         CLR LOOP FLAG
0162 00F6 0203      LI R3,>FFFE    LOAD DATA MASK
      00F8 FFFE
0163
0164 00FA C088      TOP MOV R8,R2    LOAD START ADDRESS
0165
0166 00FC 0204      TOP2 LI R4,>10   SET COUNT TO 16
      00FE 0010
0167
0168 0100 0604      LOOP1 DEC R4       DECREMENT COUNT
0169 0102 C104      MOV R4,R4      CHECK FOR END OF LOOP
0170 0104 1601      JNE CONT      IF NOT DONE CONTINUE !
0171 0106 1019      JMP EDTCK      ***CHECK TO SEE IF DONE
0172 0108 0B13      CONT SRC R3,R1  SHIFT MASK TO NEXT BIT
0173 010A CC83      MOV R3,*R2+   WRITE MASK TO MEMORY
0174 010C 0543      INV R3         INVERT DATA
0175 010E C012      MOV *R2,R0     SAVE FOR RESTORE

```

```

0176 0110 C483      MOV  R3,*R2      WRITE DISTURB DATA
0177 0112 0543      INV  R3          RESET DATA
0178 0114 C480      MOV  R0,*R2      RESTORE DATA
0179 0116 0642      DECT R2         RESET ADDRESS
0180 0118 C152      MOV  *R2,R5      READ IT BACK
0181 011A 80C5      C    R5,R3       COMPARE
0182 011C 13F1      JEQ  LOOP1       IF CORRECT DO NEXT BIT
0183 011E 2FAA      PRNT @MSG6(10)   IF NOT, OUTPUT FAIL MSG.
0120 0214
0184 0122 2E83      HEXO R3         *
0185 0124 2FAA      PRNT @MSG7(10) *
0126 0228
0186 0128 2E85      HEXO R5         *
0187 012A 2FAA      PRNT @MSG2(10) *
012C 01EA
0188 012E 2FAA      PRNT @LOC(10)  *
0130 0574
0189 0132 2E82      HEXO R2         *
0190 0134 2FAA      PRNT @CRLF(10) *
0136 01F8
0191 0138 1028      JMP  EOT        AND EXIT TEST
0192      EOTCK
0193 013A 05C2      INCT R2        INCREMENT ADDRESS
0194 013C 8242      C    R2,R9     IF IT IS LESS THAN END ADD.
0195 013E 1ADE      JL  TOP2       JUMP BACK AND FINISH
0196 0140 C186      MOV  R6,R6     GO ON ?
0197 0142 1301      JEQ  BYPAS4    YES IF NO FAIL OCCURRED
0198 0144 100E      JMP  TEST2     OTHERWISE GO TO TEST 2
0199      BYPAS4
0200 0146 0203      LI   R3,>0001  LOAD NEW MASK
0148 0001
0201 014A 0706      SETO R6        SET FLAG WHEN 1ST PAT DONE
0202 014C 10D6      JMP  TOP
0203 014E 4F      WAIT TEXT 'ONE MOMENT PLEASE'
0204 015F 0D      BYTE >D,>A,>0
0160 0A
0161 00
0205      EVEN
0206      *-----
0207      *
0208      * CHECKS ADDRESSING FAILURES
0209      *
0210      * THIS TEST WRITES THE ADDRESS OF THE LOCATION
0211      * TO THE LOCATION TO VERIFY THAT EACH ADDRESS
0212      * IN THE AREA UNDER TEST IS UNIQUE.
0213      *-----
0214      TEST2
0215 0162 C088      MOV  R8,R2     LOAD STARTING ADDRESS
0216      WRITE
0217 0164 CC82      MOV  R2,*R2+   WRITE TO LOCATION
0218 0166 8242      C    R2,R9     DONE ?
0219 0168 1AFD      JL  WRITE     IF NOT JUMP BACK
0220 016A C088      MOV  R8,R2     OTHERWISE READ IT BACK
0221      READA

```

```

0222 016C C152      MOV  *R2,R5      STORE
0223 016E 8C82      C    R2,*R2+     AND COMPARE
0224 0170 1603      JNE  ERR3        IF NOT =, INDICATE ERROR
0225 0172 8242      C    R2,R9       DONE ?
0226 0174 1AFB      JL   READA      IF NOT CONTINUE
0227 0176 1009      JMP  EOT        OTHERWISE END THE TEST
0228                ERR3
0229 0178 0642      DECT R2
0230 017A 2FAA      PRNT @MSG9(10)  ERROR MESSAGE
0231 017E 2E82      HEXD R2         *
0232 0180 2FAA      PRNT @MSG10(10) *
0233 0184 2E85      HEXD R5         *
0234 0186 2FAA      PRNT @CRLF(10) *
0235                EOT
0236 018A 045B      RT              GET NEXT COMMAND
0237                *****
0238                *
0239                *   DEFINES START AND STOP ADDRESSES
0240                *
0241                *   THIS ROUTINE SEARCHES BETWEEN START AND END
0242                *   FOR THE FIRST CONTIGUOUS BLOCK OF RAM MEMORY.
0243                *
0244                *   THIS ROUTINE DOES A NON-DESTRUCTIVE SEARCH
0245                *****
0246                SCAN
0247 018C 0704      SETD R4         DISTURB DATA = >FFFF
0248 018E 0403      CLR  R3         DATA = 0
0249 0190 C088      MOV  R8,R2      GET START ADDRESS
0250 0192 0642      DECT R2        ADJUST FOR TEST
0251 0194 0406      CLR  R6         CLR FIRST FLAG
0252                FIND
0253 0196 8242      C    R2,R9      LAST ADD. ?
0254 0198 1323      JEQ  TOOFAR     IF SO GO TO ERR. ROUTINE
0255 019A 0502      INCT R2
0256 019C C012      MOV  *R2,R0     SAVE FOR RESTORE
0257 019E CC83      MOV  R3,*R2+   WRITE TO MEMORY
0258 01A0 C052      MOV  *R2,R1     SAVE FOR RESTORE
0259 01A2 C484      MOV  R4,*R2    WRITE DISTURB DATA
0260 01A4 0642      DECT R2        MOV POINTER BACK
0261 01A6 C152      MOV  *R2,R5     STORE WRITTEN DATA
0262 01A8 8143      C    R3,R5     IS DATA = WHAT WAS WRITTEN ?
0263 01AA 1316      JEQ  MOVE      IF SO CHECK IF FIRST TIME
0264                FIND2
0265 01AC C186      MOV  R6,R6     IF FLAG = 0,STRT ADD NOT FOUND
0266 01AE 1310      JEQ  GO        SO TRY TO FIND IT
0267                SUPER
0268 01B0 C242      MOV  R2,R9     OTHERWISE THIS IS THE ENDADD
0269 01B2 CC80      MOV  R0,*R2+   RESTORE DATA
0270 01B4 C481      MOV  R1,*R2    RESTORE DATA
0271 01B6 2FAA      PRNT @MBOUND(10)
0272 01B8 028A

```

```

0272 01BA 2E88          HEXO R8          OUTPUT MEMORY BOUNDS
0273 01BC 2FAA          PRNT @TO(10)
      01BE 029F'
0274 01C0 2E89          HEXO R9
0275 01C2 2FAA          PRNT @CRLF(10)
      01C4 01F8'
0276 01C6 1010          JMP  EOSRCH          AND JUMP TO END OF TEST
0277                                STRTAD
0278 01C8 C186          MOV  R6,R6          CHECK FIRST FLAG
0279 01CA 1602          JNE  GO            IF R6 IS SET START ALREADY FOU
0280 01CC C202          MOV  R2,R8          OTHERWISE THIS IS START ADD.
0281 01CE 0706          SETO R6           SET FLAG
0282                                GO
0283 01D0 CC80          MOV  R0,*R2+       RESTORE DATA
0284 01D2 C481          MOV  R1,*R2       RESTORE DATA
0285 01D4 0642          DECT R2          RESET FOR LOOP
0286 01D6 10DF          JMP  FIND         CONTINUE
0287                                MOVE
0288 01D8 C484          MOV  R4,*R2       CHECK TO SEE IF ITS EPROM
0289 01DA 8112          C    *R2,R4
0290 01DC 13F5          JEQ  STRTAD       IF EQ, CHECK FOR START ADD.
0291 01DE 10E6          JMP  FIND2       NOW TO FIND END ADD.
0292                                TOOFAR
0293 01E0 C186          MOV  R6,R6       IF SET >F000 MAY BE THE END AD
0294 01E2 16E6          JNE  SUPER       IF SO, THAT'S SUPER
0295 01E4 2FAA          PRNT @MSG16(10)  OUTPUT 'NO RAM MEMORY FOUND'
      01E6 0278'
0296                                EOSRCH
0297 01E8 045B          RT              RETURN
0298                                *
0299                                *****
0300                                *SAGES *** MESSAGES *** MESSAGES *** MESSAGES *** ME
0301                                *****
0302 01EA 20          MSG2  TEXT ' WAS READ BACK'
0303 01F8 0D          CRLF  BYTE >D,>A,>0
      01F9 0A
      01FA 00
0304 01FB 20          MSG5  TEXT ' ****TEST COMPLETE****'
0305 0211 0D          BYTE  >D,>A,>0
      0212 0A
      0213 00
0306 0214 44          MSG6  TEXT 'DATA BUS IN ERROR, '
0307 0227 00          BYTE  >0
0308 0228 20          MSG7  TEXT ' WAS WRITTEN, BUT '
0309 023A 00          BYTE  >0
0310 023B 41          MSG9  TEXT 'ADDRESS PROBLEM FOUND. LOCATION '
0311 025B 00          BYTE  >0
0312 025C 20          MSG10 TEXT ' WAS IN ERROR WITH ADDRESS '
0313 0277 00          BYTE  >0
0314 0278 4E          MSG16 TEXT 'NO MEMORY FOUND'
0315 0287 0D          BYTE  >D,>A,>0
      0288 0A
      0289 00
0316 028A 4D          MBOUND TEXT 'MEMORY UNDER TEST =>'

```

```
0317 029E 00          BYTE >0
0318 029F 20 TO      TEXT ' TO '
0319 02A3 00          BYTE >0
0320 02A4 54 BANNER TEXT 'TM990/201-/206 DEMO SOFTWARE
0321 02C5 52          TEXT 'REV.A      8/02/78'
0322 02D6 0D          BYTE >D,>A,>0
      02D7 0A
      02D8 00
0323 02D9 0D PROMPT  BYTE >D,>A
      02DA 0A
0324 02DB 3F          TEXT '?? '
0325 02DE 07          BYTE >7,>0
      02DF 00
0326 02E0 49 PROMT   TEXT 'INPUT HEX PATTERN, DEFAULT = '
0327 02FD 00          BYTE >0
0328 02FE 0D HLIST   BYTE >D,>A
      02FF 0A
0329 0300 43          TEXT 'COMMANDS:'
0330 0309 0D          BYTE >D,>A,>A
      030A 0A
      030B 0A
0331 030C 48          TEXT 'H - HELP, PRINTS THIS HELP LIST'
0332 032B 0D          BYTE >D,>A
      032C 0A
0333 032D 51          TEXT 'Q - QUIT, BACK TO TIBUG'
0334 0344 0D          BYTE >D,>A
      0345 0A
0335 0346 53          TEXT 'S - SEARCH FOR RAM BOUNDS'
0336 035F 0D          BYTE >D,>A
      0360 0A
0337 0361 20          TEXT '      SEARCHES FOR THE FIRST CONTIGUOUS BLOCK'
0338 038C 20          TEXT ' OF RAM '
0339 0394 0D          BYTE >D,>A
      0395 0A
0340 0396 49          TEXT 'I - INITIALIZE MEMORY BOUNDS'
0341 03B2 0D          BYTE >D,>A
      03B3 0A
0342 03B4 50          TEXT 'P - PATTERN MEMORY'
0343 03C6 0D          BYTE >D,>A
      03C7 0A
0344 03C8 20          TEXT '      WRITE PATTERN TO ALL LOCATIONS UNDER TEST'
0345 03F5 0D          BYTE >D,>A
      03F6 0A
0346 03F7 56          TEXT 'V - VERIFY RAM OPERATION'
0347 040F 0D          BYTE >D,>A
      0410 0A
0348 0411 20          TEXT '      ADDRESSING AND DATA TEST;'
0349 042E 20          TEXT ' THE DATA TEST CHECKS EVERY BIT.'
0350 044E 0D          BYTE >D,>A
      044F 0A
0351 0450 20          TEXT '      THE ADDRESS TEST CHECKS TO SEE THAT ALL'
0352 047B 20          TEXT ' THE ADDRESSES ARE UNIQUE'
0353 0494 0D          BYTE >D,>A,>0
      0495 0A
```

```

0354      ♦      IF AN INVALID HEX DIGIT IS ENTERED.
0355      ♦.....
0356      BOUNDS
0357      0482 0200      LI  R0,>0460      R0 = BRANCH
                0484 0460
0358      0486 0201      LI  R1,ZIP1      IF <CR> BRANCH TO OK1
                0488 04BA/
0359      048A A04A      A    R10,R1      ADD BASE ADDRESS
0360      048C 0202      LI  R2,>0460      R2 = BRANCH
                048E 0460
0361      0490 0203      LI  R3,ERROR1    IF ERR BRANCH TO ERROR1
                0492 04F3/
0362      0494 A0CA      A    R10,R3      ADD BASE ADDRESS
0363      0496 2FAA      PRNT @CRLF(10)
                0498 01E2/
0364      049A 2FAA      PRNT @ENTRY1(10)  PRINT PROMPT 1
                049C 04FA/
0365      049E 2E88      HEXD R8      OUTPUT DEFAULT
0366      04A0 2FAA      PRNT @TIC(10)
                04A2 04EE/
0367      04A4 2E44      HEXI R4      WAIT FOR START ADDRESS
0368      04A6 FF90      DATA >FF90  POINTS TO R0
0369      04A8 FF94      DATA >FF94  NON-NUMERIC OR INVALID CHAR
0370      04AA 0284      CI   R4,>FF90  INFRINGE ON WP ?
                04AC FF90
0371      04AE 1202      JLE  BYPAS      IF NOT GO ON
0372      04B0 0208      LI  R8,>FF90    IF SD ENTER >FF90
                04B2 FF90
0373      BYPASS
0374      04B4 C204      MOV  R4,R8      R8 = START ADDRESS
0375      04B6 0248      ANDI R8,>FFFE    MAKE IT EVEN
                04B8 FFFE
0376      ZIP1
0377      04BA 0201      LI  R1,ZIP2      IF <CR> BRANCH TO OK2
                04BC 04E4/
0378      04BE A04A      A    R10,R1      ADD BASE ADDRESS
0379      OK2
0380      04C0 2FAA      PRNT @CRLF(10)
                04C2 01E2/
0381      04C4 2FAA      PRNT @ENTRY2(10) PRINT PROMPT 2
                04C6 051E/
0382      04C8 2E89      HEXD R9      OUTPUT DEFAULT
0383      04CA 2FAA      PRNT @TIC(10)
                04CC 04EE/
0384      04CE 2E44      HEXI R4      WAIT FOR END ADDRESS
0385      04D0 FF90      DATA >FF90  POINTS TO R0
0386      04D2 FF94      DATA >FF94  NON-NUMERIC OR INVALID CHAR
0387      04D4 0284      CI   R4,>FF90  INVADE WP ?
                04D6 FF90
0388      04D8 1202      JLE  BYPASS      IF NOT GO ON
0389      04DA 0209      LI  R9,>FF90    OTHERWISE ENTER >FF90
                04DC FF90
0390      BYPASS
0391      04DE C244      MOV  R4,R9      R9 = END ADDRESS
  
```

```

    04E2 0504'
0394 04E4 2E44      HEXI R4      WAIT FOR END ADDRESS
0395 04E6 FF90      DATA >FF90    POINTS TO R0
0396 04E8 FF94      DATA >FF94    NON-NUMERIC OR INVALID CHAR
0397 04EA 0284      CI R4,>FF90    INVADE WP ?
    04EC FF90
0398 04EE 1202      JLE BYPASS     IF NOT GO ON
0399 04F0 0204      LI R4,>FF90    OTHERWISE ENTER >FF90
    04F2 FF90
0400                                BYPASS
0401 04F4 C244      MOV R4,R9      R9 = END ADDRESS
0402 04F6 0249      ANDI R9,>FFFE  MAKE IT EVEN
    04F8 FFFE
0403                                ZIP2
0404 04FA 2FAA      PRNT @CRLF(10)
    04FC 01F8'
0405 04FE 8248      C R8,R9       ARE ENTRIES IN ORDER ?
0406 0500' 1B03     JH ERROR1     IF ERR PRINT ERR MSG.
0407 0502 045B     RT           RETURN
0408                                TIC
0409 0504 3D       TEXT '<=>'
0410 0507 07       BYTE >7,>0
    0508 00
0411                                ERROR1
0412 0509 2FAA      PRNT @ERRMSG(10)  PRINT ERROR MSG.
    050B 0555'
0413 050E 10C3     JMP BOUNDS    AND JUMP BACK
0414                                ENTRY1
0415 0510 49       TEXT 'INPUT HEX START ADDRESS, DEFAULT = '
0416 0533 00       BYTE >0
0417                                ENTRY2
0418 0534 49       TEXT 'INPUT HEX END.ADDRES, DEFAULT = '
0419 0554 00       BYTE >0
0420                                ERRMSG
0421 0555 0D       BYTE >D,>A
    0556 0A
0422 0557 2A       TEXT '***ERROR***'
0423 0562 00       BYTE >0
0424                                INVCMD
0425 0563 20       TEXT ' INVALID COMMAND'
0426 0573 00       BYTE >0
0427                                LOC
0428 0574 4C       TEXT 'LOCATION '
0429 057D 00       BYTE >0
0430                                *::::::::::::::::::::::::::::::::::::::::::::::::::
0431                                END START
  
```

0000 ERRORS

APPENDIX E

PARTS LIST

Symbol	Description	TM 990/201			
		-41	-42	-43	-44
C1-C6, C11-C14, C19-C24 C29-C32, C37-C45, C48-C55 C56-C59, C64, C66, C67	Capacitor, 0.047 uF	x			
C1-C9, C11-C45 C48-C64, C66-C71	Capacitor, 0.047 uF		x	x	x
C10, C47	Capacitor, 68 mFd, 10 %	x	x	x	x
C46	Capacitor, 22 mFd, 10 %	x	x	x	x
C65	Capacitor, 2.2 uF	x	x	x	x
R1, R2	Resistor, 4.7 K ohm, $\frac{1}{4}$ W	x	x	x	x
S1	Switch	x	x	x	x
U1, U20, U46	IC, SN74LS244N, Line Driver	x	x	x	x
U2, U11, U21, U30	IC, SN74LS243N	x	x	x	x
U3, U4, U12, U13, U22, U23, U31, U32	TMS 2114	x			
U3-U6, U12-U15, U22-U25, U31-U34	TMS 2114		x		
U3-U10, U12-U19, U22-29, U31-U38	TMS 2114			x	x
U39, U41, U47, U50	IC, SN74LS241N, Line Driver	x	x	x	x
U40	Network, SN74LS02N	x	x	x	x
U42	EPROM Memory Decode PROM	x	x	x	x
U43	Resistor, Fixed Array, 4.7 K	x	x	x	x
U44	RAM Memory Decode PROM	x	x	x	x
U45, U51	Network, SN74LS138N	x	x	x	x
U48	Network, SN74LS00N	x	x	x	x
U49	Network, SN74LS04N	x	x	x	x
U52	Network, SN74S22N	x	x	x	x
U53	Network, SN74LS20N	x	x	x	x

PARTS LIST, Continued

Symbol	Description	TM 990/201			
		-41	-42	-43	-44
U54, U55	Network, SN74LS74N	x	x	x	x
U56-U57	TMS 2716	x	x	x	
U58-U59	TMS 2716		x	x	
U60-U63	TMS 2716			x	
U64-U65	TMS 2716	x	x	x	
U66-U67	TMS 2716		x	x	
U68-U71	TMS 2716			x	
VR1	Voltage Regulator, neg, 3 terminal	x	x	x	x

PARTS LIST, Concluded

Symbol	Description	TM 990/206	
		-41	-42
C1-C9, C11-C45	Capacitor, 0.047 uF	x	x
C48-C55	Capacitor, 0.047 uF	x	x
C10, C47	Capacitor, 68 mFd, 10 %	x	x
R1	Resistor, 4.7 K ohm, $\frac{1}{4}$ W	x	x
R3	Resistor, 68 ohm, $\frac{1}{4}$ W, 5 %	x	x
S1	Switch	x	x
U2, U11, U21, U30	IC, SN74LS243N,	x	x
U3-U6, U12-U15, U22-U25, U31-U34	TMS 2114	x	
U3-U10, U12-U19, U22-29, U31-U38	TMS 2114		x
U39, U41, U50	IC, SN74LS241N, Line Driver	x	x
U40	Network, SN74LS02N	x	x
U43	Resistor, Fixed Array, 4.7 K	x	x
U44	RAM Memory Decode PROM	x	x
U45	Network, SN74LS138N	x	x
U46	IC, SN74LS244N, Line Driver	x	x
U48	Network, SN74LS02N	x	x
U49	Network, SN74LS04N	x	x
U52	Network, SN74S22N	x	x
U53	Network, SN74LS20N	x	x
U54	Network, SN74LS74N	x	x

✓

✓

✓

INDEX

In the page number list of this alphabetical index, subject matter is covered by a table if a T precedes the page number, or is covered by a figure if an F precedes the page number.

Address Map Options.....	4-2
Addressing Summary.....	4-5
Applicable Documents.....	1-4
Backplane/P1 Pin Assignments used by TM 990/201 Board.....	T4-12
Board Access Time.....	2-2
Board Dimensions.....	F1-3
Configure Memory Map.....	2-4, 2-5, 5-4
Decode PROM Functional Diagrams.....	FA-3
EPROM Decode Logic.....	4-2, F4-4
EPROM Examples.....	3-7
EPROM Section.....	4-2
FAST/SLOW Jumper (J1/J2) Positions vs Memory Access Time.....	T4-7
General, Installation and Operation.....	2-1
General, Memory Placement and Selection.....	3-1
General, Theory of Operation.....	4-1
General, TM 990/206 RAM-Only Expansion Board.....	5-1
Installation and Operation for TM 990/206.....	5-3
INSTALLATION AND OPERATION.....	Section 2
Interface Description.....	4-9
INTRODUCTION.....	Section 1
Manual Organization.....	1-4
Memory Access Speed.....	2-2
Memory Access Time and J1/J2 Settings.....	T2-2
Memory Block Locations.....	F3-9
Memory Configuration Switch Array (S1).....	3-1, F3-2
Memory Mapping.....	2-2
Memory Placement and Selection for TM 990/206.....	5-3
MEMORY PLACEMENT AND SELECTION.....	Section 3
Memory Placement by Blocks.....	3-7
Memory Placement.....	3-1
Memory Speed.....	4-5
Memory Timing.....	4-7
Operation of TM 990/206.....	5-3
PARTS LIST.....	Appendix E
Power and Terminal Hookup.....	2-1
PROGRAMMING ADDRESS DECODE PROMS FOR ALTERNATE ADDRESS MAPS....	Appendix A
PROM PROGRAM SHEETS.....	Appendix C

Index, Concluded

RAM (only) Configuration for Model TM 990/206.....	F5-6
RAM Decode Logic.....	4-5, F4-6
RAM Example.....	3-8
RAM Precedence Logic.....	4-9, F4-11
RAM PROM Decode Programming Example.....	TA-2
READY Logic.....	4-9
Required Equipment.....	2-1
Select Wait State.....	2-4, 2-5, 5-4
Set-up with TM 990/100MA or TM 990/101MA Microcomputer.....	2-2
Set-up with TM 990/1481 Microcomputer.....	2-4
SLOW/FAST Memory Jumper Placement.....	F4-7
Specifications for TM 990/206.....	5-1
Specifications for TM 990/201.....	1-4
Static RAM Section.....	4-1
THEORY OF OPERATION.....	Section 4
TM 990/201 Address Decode Logic Block Diagram.....	F4-3
TM 990/201 Block Diagram.....	F4-1
TM 990/201 EPROM Decode Program.....	FA-5
TM 990/201 Memory Expansion Board.....	F1-2
TM 990/201 Memory Map Example.....	F2-3
TM 990/201 Memory Timing.....	F4-8
TM 990/201 Power Consumption vs. Sizes.....	T1-4
TM 990/201 Product Matrix.....	T1-1
TM 990/201 RAM Decode PROM Program.....	FA-4
TM 990/201 RAM Ready Logic.....	F4-10
TM 990/201 SCHEMATICS.....	Appendix B
TM 990/201-41, -42, -43 EPROM Memory Configurations.....	F3-3
TM 990/201-41, -42, -43 RAM Memory Configurations.....	F3-5
TM 990/201-44 EPROM Memory Configurations.....	F3-4
TM 990/201-44 Memory Map Example.....	F2-5
TM 990/201-44 RAM Memory Configurations.....	F3-6
TM 990/206 Memory Expansion Board.....	F5-2
TM 990/206 Memory Map Example.....	F5-5
TM 990/206 Power Consumption vs Sizes.....	T5-3
TM 990/206 Product Matrix.....	T5-1
TM 990/206 RAM-ONLY MEMORY EXPANSION BOARD.....	Section 5
TM 990/422 DEMONSTRATION SOFTWARE.....	Appendix D
TM 990/510A OEM Chassis Backplane Schematic.....	F4-11
Unpacking.....	2-1

TM 990/201 AND TM 990/206 MEMORY BOARDS

USER RESPONSE SHEET

It is our desire to provide you with the best documentation possible. After using this manual, please complete this sheet and mail it postpaid to us. Your comments will be appreciated; however, do not use this form as a questionnaire for additional information. Any questions or problems should be directed to your TI distributor.

1. Is the manual well organized? Yes _____ No _____ Comments: _____

2. Is text clearly presented and adequately illustrated? Yes _____ No _____

Comments: _____

3. What subject matter could be expanded or clarified? _____

4. Are the S1 switch settings adequately covered? Yes _____ No _____

Comments: _____

5. Is the PROM decoder adequately covered? Yes _____ No _____ Comments: _____

6. Do you wish more data to clarify an application? Yes _____ No _____

Comments: _____

7. Please explain the application intended for your board:

School Course _____ Home _____ Evaluation _____ OEM Application _____ Other _____

If OEM Application, please describe: _____

8. Other comments _____

Name: _____

Address: _____

City: _____ State: _____ Zip: _____

School (if applicable): _____ Major _____ Year _____

FOLD



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 3 JOHNSON CITY, TN
POSTAGE WILL BE PAID BY ADDRESSEE



TEXAS INSTRUMENTS INCORPORATED
ATTN: TECHNICAL PUBLICATIONS, M/S 3526
ERWIN HIGHWAY
P.O. DRAWER 1255
JOHNSON CITY, TN. 37605-9987

FOLD

✓

✓

✓





